Home » Lumens » Lumens HDL410 Coordinate Nureva Device User Guide 🖔



Lumens HDL410 Coordinate Nureva Device User Guide



Contents

- 1 Lumens HDL410 Coordinate Nureva Device User
- 2 Introduction to HDL410 coordinate
- 3 Documents / Resources
 - 3.1 References

Lumens HDL410 Coordinate Nureva Device User Guide


Introduction to HDL410 coordinate

- The coordinate setting guide in this document only works with firmware v1.7.18.
- Instead of using solely mist technology in coverage map, zones will be used.
- CamConnect directs camera (s) when voice sources are detected in Nureva zones.
- This guide assumes familiarity with HLD410 setup and room level setup if not please see below first;

https://www.mylumens.com/Download/Nureva%20HDL410%20Setting%20Guide%202023-1128.pdf

Step1: Login Nureva Console to set coverage map.


- Login your Nureva device.
- Select HDL410 device to set coverage map.



Step2: Define plan in HLD410 coverage map.

- Adjust the default dimensions within the coverage map to accurately define your room size.
- Create and position zones to be used with local integrations.


Below is an example (for depiction purpose only):



Step3. Operating and setting up CamConnect's zone map


- Connect "HLD410 (coordinate)" microphone. When microphone and cameras are connected (HDMI interface)
- Click "Zone Map" to the setting page of zone map. Clink "Refresg Layout" to import and syncing Nureva zones
 into CamConnect.

Note: Due to the system limitation, the Zone name may not be changed if the zone renames on Nureva.



Step4. Set the Preset No. by Zone No.

• Make sound to trigger the HDL410 microphone and set up the preset No. according to the Zone No.



Best Practices

- 1. Operate HDL410 coordinate ONLY in HDMI interface of CamConnect.
- 2. Do Not place zones too close to each other.
- 3. Avoid zones overlap.
- 4. Do not place zones too close to room wall.
- 5. Avoid using real size (dimension) of room, instead imagine a virtual dimension around your area of interest.
- 6. If there are random jumping or pick up of voice source (green LED in HDMI), fine tune your audio trigger level.
- 7. After defining "virtual room dimension and zones" go to Nureva and recalibrate your HDL410.

8. Read carefully HDL410 Nureva's recommendation when setting up a room.



Read More About This Manual & Download PDF:

Documents / Resources



<u>Lumens HDL410 Coordinate Nureva Device</u> [pdf] User Guide HDL410, HDL410 Coordinate Nureva Device, Coordinate Nureva Device, Nureva Device, Device

References

- O Lumens Pro AV Technology | Lumens
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.