



LUMENS RM-W Wireless Microphone Instruction Manual

[Home](#) » [Lumens](#) » LUMENS RM-W Wireless Microphone Instruction Manual 

LUMENS RM-W Wireless Microphone




Contents

- [1 Download RM Device Finder](#)
- [2 Find Device IP by RM Device Finder](#)
- [3 YAMAHA RM-W Desktop Microphone Setting](#)
- [4 Identify Microphone](#)
- [5 Cam Connect Pro \(AI-BOX1\) Settings](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

Download RM Device Finder

Download Link:

<https://info.uc.yamaha.com/rm-device-finder>



Windows 10 (32bit/64bit) / Windows 11

Compatible Models

- RM-CG
- RM-CR(*1)
- RM-TT
- RM-WAP-8

*1) rear port only

Important Notice

- If the [ETHERNET SWITCH SETTINGS] is set to [Separated] mode (default) and you want to set an RM-CR Dante terminal and corporate terminal to the same IP segment, connect both terminals to the same network switch. If you connect them to different network switches, "RM Device Finder" and "ProVisionaire Control" will not be able to detect the device.

Main Revisions and Enhancements

New Functions


- The RM-TT and RM-WAP-8 can now be detected and the Web GUI can be displayed.
- Added a firmware update function (compatible with the RM-CR, RM-CG, RM-TT, and VXL1-16P).



Licensing Agreement & Download

☒ I agree to the licensing terms outlined below.*

DOWNLOAD

Find Device IP by RM Device Finder



Model	Label	Version	IP Address	MAC Address	Subnet Mask	Web UI
RM-CG	Y001-Yamaha-...	V2.0.0	192.168.0.16	AC:44:F2:71:15:48	255.255.255.0	
RM-WAP-16	Y001-Yamaha-...	1.9.11	192.168.0.20	AC:44:F2:B2:78:82	255.255.255.0	

YAMAHA RM-W Desktop Microphone Setting

Set up Yamaha RM-W

- Use PoE to power on RM-WAP16/RM-WAP-8.

RM-WAP-16/RM-WAP-8



- Power on RM-W Wireless Microphone and press “pair” button 3-5 secs and it will flash blue twice. The microphone pair successfully to RM-WAP-16/RMWAP-8.

RM-W Wireless Microphone



Set a password of Yamaha RM-W

- Enter Device IP address into browser.
- Specify a password in the password settings window, and then click the [SET PASSWORD] button.

RM-WAP Device Manager

Please set a password

Device Management Account 

Device Management User Account Password



Repeat Password



SET PASSWORD

Login in Yamaha RM-W Webpage

- Type the password into the login window, and then click the [LOGIN] button.



YAMAHA

RM-WAP Device Manager

Your session timed out. Please log in again.

Password

.....




Remember me

LOGIN

Identify Microphone



- Click the button to identify the device. After clicking, microphone will flash purple.



Microphone Status

- Go to webpage "Home" tab


- Mic shows orange means it is connected.
- Audio shows green means it can receive the voice.
- Dante channel No. matches Cam Connect Pro



Cam Connect Pro (AI-BOX1) Settings

Support Device & Settings

1. Pull down the Device item and selects [Yamaha RM-W]
2. Enter the IP address of Yamaha RM-W
3. Switch the [Connect] button to connect with Yamaha RM-W



Notice: It's not recommend to use Yamaha CM-CR, RM-W, RM-CG in the same subnetwork. Yamaha CM-CR will integrate all microphone into one source.



MyLumens.com



Contact Lumens



Lumens®

Documents / Resources



[LUMENS RM-W Wireless Microphone](#) [pdf] Instruction Manual
RM-W Wireless Microphone, RM-W, Wireless Microphone, Microphone

References

- [🌐 Lumens – Pro AV Technology | Lumens](#)
- [🌀 RM Device Finder](#)
- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth

