




LUMERI Q120 Projector Instruction Manual

[Home](#) » [lumeri](#) » LUMERI Q120 Projector Instruction Manual 

LUMERI

Q120 Projector Instruction Manual



Note: As the product system is updated from time to time, the specific operation content is based on the actual situation. This product is only suitable for projections of images & video. and may not be used for room lighting.

Contents

- [1 Important Safeguards](#)
- [2 Accessories List](#)
- [3 Projector Overview](#)
- [4 Specification](#)
- [5 Multimedia Supported Files](#)
- [6 Remote Control](#)
- [7 Focus / Keystone Correction](#)
- [8 How to Set the Menu](#)
- [9 Standard Setting](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)
- [11 Related Posts](#)


Important Safeguards

1. Please read the manual carefully before operating the projector. To ensure a stable power supply, please use a standard power cable.
2. Please use the power supply and cable indicated on the rating label. The projector should be kept away from clothes, sofas, and anything that may block the ventilation scoop. Please keep the unit away from flammable and explosive materials.
3. Please do not disassemble the unit yourself as this will invalidate the warranty service. To protect your eyes, do not stare directly at the lens when the projector is on. The projector must be kept away from water and any other liquids.
4. To prevent electric shock, please keep the projector out of the rain and away from moisture. It is recommended to switch off the projector after it has run for 6 hours non-stop. Please use the original foam and other cushioning materials when transporting the projector.
5. If the projector does not work, please contact the authorized service agent.

Accessories List


AV signal cable x1
Remote control x1
Power adapter it 1
User manual x1

Projector Overview



1. Infrared Port
2. USB Port
3. HDM I Port
4. VGA Port
5. AV Port
6. Audio Output
7. DC 12V Adapter

1.



- Left: move left or volume down
2. Right move right or volume up
3. Down: move down
4. Up: move up
5. Menu: operate multiple functions
6. Source: confirm the signal input source
7. Power Button: power on or off

8. Power Indicator

Specification

Model	LCD projector	Image system	LCD
Lamp	LED	Native resolution	480×320,support 1080P
Language	English, 25 languages	Input voltage	DC 12V/2A
		Size	168x110x70mm
Aspect Ratio	16:9/4:3	Working temp	0-35°C
Weight	0.5 KG	Input voltage	HDMI /USBNGA/AV/SD/ATV (Optional match)
Operation mode	Manual / Remote control	Output	Headphone


Multimedia Supported Files

Image Format	JPG/PNG/BMP/JPEG
Video Format	MP4/MKV/MOV/WMV/RMVB/RM/AVI/FLV/TRP/V0B/3GP/DIVX/TP/TS/MPG/M2TS/F4V/DAT
Audio Format	MP3/AAC/WAV/FLAC/WMA/M4A
File Format	TXT



The projector does not support Dolby audio decoding.


Remote Control



1. Power
2. Forward
3. Previous
4. Mute
5. Backward
6. Play
7. Stop

8. Source
9. Up / down / left / right
10. Menu
11. Next
12. Electronic Menu
13. Confirm
14. Exit

Focus / Keystone Correction



I. Image focus

Turn the lens clockwise to the projector, and thereafter slowly turn it counterclockwise. At the same time, check the resolution point. The best position of the lens will be determined when the image is clear.

How to Set the Menu

Select Setup in the main interface, first press the left/right keys to select the sub-menu, the second set up the


mode you need, and finally press the OK key to confirm.

Submenu:

PICTURE: Picture Mode \ Contrast \ Brightness \ Color \ Tint \ Sharpness \ Color Temperature \ Noise Reduction.

SOUND: Sound Mode \ Treble \ Bass.


OPTION: OSD Language \ Aspect Ratio \ Projection Mode \ Factory Reset \ Software Upgrade \ Version.



•How to Select Source

Step 1: Select the source you want in the main interface, such as HDMI, AV, etc.

Step 2: Press the OK button on the remote control to enter into the corresponding source interface.




Note: When the projector is in the no signal interface, please press the source button on the remote control to select the home page or other source.

•How to Play Multimedia

Step 1: Select "Media" in the main interface.

Step 2: After entering the interface, select the files you want.



Standard Setting

Refer to the data in the table below to place the projector away from the projection screen according to the preset graphic size. When installing, place the projector on a solid, stable countertop. The airframe should be well ventilated. Do not cover or block the vents. There should be no obstructions within 30cm of the vents.


Aspect ratio	16:9
Picture size (inch)	Projection distance (m)
50"	2.11
70"	2.96
100"	4.23
120"	5.07

Note: The above data is for reference only, please refer to the physical measurement.
This product is only suitable for projections of images & video, and may not be used for room lighting.



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

Documents / Resources

	LUMERI Q120 Projector [pdf] Instruction Manual Q120 Projector, Q120, Projector
---	---

References

- [User Manual](#)