

LUMITASK Store XTV Rechargeable Multi Light User Guide

Contents

- [1 User Guide](#)
- [2 XTV](#)
- [3 Rechargeable Multipurpose Twin-Bright Stereoscopic Flex Light](#)
- [4 Operating the light](#)
- [5 Maintaining the light](#)
- [6 Unpacking the light](#)
- [7 Required Tools](#)
- [8 Need Help?](#)
- [9 Mounting the light](#)
- [10 Special Notice](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)
- [12 Related Posts](#)

By SewLITE™

xLITE Versa™

User Guide

XTV

Rechargeable Multipurpose Twin-Bright Stereoscopic Flex Light

Thank you for purchasing the compact and powerful cord-free SewLite **xLITE Versa™** LED Micro Task Light. The ultimate All-inOne tool for all your light needs. Refer to guide before using.

Operating the light

Turn ON-OFF with side button near bottom. Single Click or plugin Flex Light(s) for ON, double-click for OFF. Use with one or two Flex Lights. Attach / de-attach to any smooth flat surface using washable included **NanoTape**; or, wear on your clothing using magnet clamping plate. Adhere to all medical device warnings for magnets. Battery level is shown as 4 LED dots. Finally, charge up to two cell phones using both USB-A ports.

Maintaining the light

Your light is maintenance-free and water-dust resistant by design. It can withstand steam, food, splashes, and even occasional drops! If it should no longer stick, simply wash tape and let air-dry. Use small tiny amount of soap if needed. DO NOT scrub tape. NEVER clean with alcohol or solvents.

Unpacking the light

Identify and remove all contents from packaging.

5000 mAh Smart Power Bank with ON/OFF Switch
(2) USB Flex Micro Task Lights

(2) **NanoDOTZ™ NanoTape** Dots (keep liners)
USB Micro Charging Cord
Detachable Magnet Plate

Required Tools

Isopropyl or cleaner (for cleaning mounting surfaces) Warm water with soap (for renewing tape surface)
ATTENTION: Special **NanoTape** sticks to all surfaces. When not in use, cover open tape with liner.

Need Help?

If you need help troubleshooting or require additional assistance with this product our customer support staff is ready to assist you.



General Information

Online: [Sewlite.com](https://sew-lite.com)

Genuine Parts

Email: staff@neutek.us

Customer Service 8a – 2p, Mon- Thr, Arizona Time
info@sew-lite.com (excluding US Holidays)
(844) LED-TASK

Mounting the light

Installing the micro task light requires 3-steps. There are ZERO bulb changes, batteries to replace, cords to loose, or tape to replace. Simply re-mount over and over on any clean smooth surface. Or wear on your clothing to place light in front of you. Bend Flex Lights for desired best lighting.

- Make sure mounting surface is free of grease or dirt
- Peel Single Tape Liner and attach to Battery first
- Peel second Tape Liner and stick to machine surface.
- Remove battery with gentle steady twist. Avoid prying.
- Clean NanoTape surface if no longer holding well.
- Double-stack NanoTape for best curved surface hold
- Recharge battery up to 1000x. Clean tape up to 100x.

Special Notice


After pressing battery OFF button it is normal to see a small “flicker” coming from lights. There is no effect on battery life.

While charging the battery, the ON-OFF button is defaulted to ON and will cause the Flex Lights to remain ON if plugged in. To maximize battery life, unplug charging cable at 100% charged.

Battery runtime can vary depending on its configuration. Single Flex Light is up to 20hrs while two Flex Lights is up to 10hrs.

This light is for general purpose hobby task illumination only. ©2021 Sewlite. All rights reserved. Patents pending.

Documents / Resources

	<div><div>LUMITASK Store XTV Rechargeable Multi Light [pdf] User Guide</div><div>XTV Rechargeable Multi Light, XTV, Rechargeable Multi Light, Multi Light, Light</div></div>
---	--

References

- [🌐 LUMITASK - micro LED Task Lights for Sewing, Quilting, Crafting, etc. – LUMITASK STORE](#)