



LUMME LU-3630 Induction Cooker User Manual

[Home](#) » [LUMME](#) » LUMME LU-3630 Induction Cooker User Manual 

LUMME

LU-3630 Induction Cooker
User Manual



INDUCTION COOKER
USER MANUAL
LU-3630

Contents

1 IMPORTANT SAFETY INSTRUCTIONS

2 CLEANING AND MAINTENANCE

3 SPECIFICATION

4 Documents / Resources

4.1 References

5 Related Posts

IMPORTANT SAFETY INSTRUCTIONS

Read this manual carefully before using the appliance and save it for future reference.

- Before first use, check the device specifications and the power supply in your network.
- Use only for domestic purposes according to the instruction manual. It is not intended for industrial use.
- For indoor use only.
- Do not operate any product with damage.
- Keep the power cord away from sharp edges and hot surfaces.
- Do not pull the cord. Always take the socket. Do not reel the cord around the device housing.
- Never attempt to disassemble and repair the item by yourself. If you encounter problems, please contact the nearest customer service center.
- Using accessories or replacement parts that are not recommended or sold by the manufacturer may cause damage to the item.
- Always unplug the item and let it cool down before cleaning and removing parts. Keep unplugged when not in use.
- To avoid electric shock and fire, do not immerse in water or other liquids. If this occurs, immediately unplug it and contact service center for inspection.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not use near explosives and flammable materials.
- Do not move the appliance until it is completely cool.
- Do not touch the metal parts of the device, because they get very hot during operation.
- Do not use hot plate for drying clothes, papers or other objects. Only use it for cooking.
- Always check the temperature of prepared meals, especially if it is suggested to children. Allow the dish to cool down after cooking.

CLEANING AND MAINTENANCE

- Unplug the appliance from the power supply before cleaning.
- Let the unit cool down completely.
- Wipe external surfaces with a damp cloth with some washing-up liquid. Do not use abrasive detergents, any organic solvent or aggressive chemicals.

SPECIFICATION


Model	Power supply	Power	Net/Gross Weight	Gift box dimension (L xW xH)	Cookware Ø
LU-3630	230 V ~ 50 Hz	2000 W	1.58 /1.93 kg	305 x 84 x 365 mm	12-26 cm

WARRANTY DOES NOT COVER SUPPLIES (filters, ceramic and non-stick coating, rubber seals, etc.)
Production date is available in the serial number located on the identification sticker on the gift box and/or on sticker on the device. The serial number consists of 13 characters, the 4th and 5th characters indicate the month, the 6th and 7th indicate the year of device production. Producer may change the complete set, appearance, country of manufacture, warranty and technical characteristics of the model without notice. Please check when purchasing device.

LUMM

Producer: COSMOS FAR VIEW INTERNATIONAL
LIMITED-ROOM 701, 16 APT, LANE
165, RAINBOW NORTH
STREET, NINGBO, CHINA
Made in China

Documents / Resources

	LUMME LU-3630 Induction Cooker [pdf] User Manual LU-3630 Induction Cooker, LU-3630, Induction Cooker, Cooker
---	---

References

- [Интернет-магазин Lumme](#)