



LUMME LU-SM1252B Nut Maker User Manual

[Home](#) » [LUMME](#) » LUMME LU-SM1252B Nut Maker User Manual 

LUMME

LU-SM1252B Nut Maker
User Manual



Contents

1 Parts list:

2 BEFORE FIRST USE

3 USING THE DEVICE

4 CLEANING AND MAINTENANCE

5 SPECIFICATION

6 Documents / Resources

6.1 References

Parts list:

1. Housing
2. Handles
3. Handles fixator
4. Operation light indicator
5. Heating light indicator



Real set of the appliance could be different from listed in the User manual. Check once buy..

CAUTION

Read this manual carefully before using the appliance and save it for future reference.

- Before the first use, check the device specifications and the power supply in your network.
- It is not intended for industrial use.
- For indoor use only. Use only for domestic purposes according to the instruction manual.
- Do not use with damaged cord, plug or other injuries.
- Keep the power cord away from sharp edges and hot surfaces.
- Do not pull the cord. Always take the socket. Do not reel the cord around the device housing.
- Never attempt to frame and repair the appliance by yourself. If you meet problems, please contact the nearest customer service center.

- Using accessories or replacement parts that are not recommended or sold by the manufacturer may cause damage to the appliance.
- Always unplug the appliance and let it cool down before cleaning and removing parts. Keep unplugged when not in use.
- To avoid electric shock and fire, do not immerse in water or other liquids. If this occurs, immediately unplug it and contact service center for inspection.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

BEFORE FIRST USE

- Before the first use grease grill pates with butter or margarine.
- Turn on the appliance and let to heat for 10 minutes in a closed state.
- Then unplug the appliance, let it to cool, then wipe working surface with a damp cloth.

USING THE DEVICE

- Plug the device to the power supply. Device starts to heat up, the indicator lights (red and green) will be on.
- Once the cooking surface has reached the preset temperature, the heating indicator light (the green one) will be off. You can start cooking.
- Please don't open the device during heating.
- Place all ingredients to the working surface, close the lid.
- Fix the lid with handles fixator.

CAUTION: Be careful, hot steam could come out!

- Average cooking time is 6-8 minutes. Anyway you can vary the time of cooking to taste.
- Open the lid and take out prepared meal with wooden paddle. Please, do not use sharp metal things to not damage non-stick coating.
- Close the lid to keep warm for cooking next.
- Unplug the device after cooking.

CLEANING AND MAINTENANCE

- Unplug the device before the cleaning.
- Let the device to cool.
- Working surface and edges should be wiped with paper towel or soft cloth.
- If rest of stuffing stuck to the surface, pour a little bit oil on working surface and heat up for 1-2 minutes. Switch off the device and wipe the working surface after 5 minutes.
- Outer parts of device might be cleaned with wet cloth. Avoid contact of inner part with liquids and oil.
- Never sink the device into the water or other liquids.
- Device can't be washed in dishwasher.
- Do not use abrasive agents, organic solvents and corrosive liquids.

SPECIFICATION

Model: LU-SM1252B

Power supply: 230 V ~ 50 Hz

Net weight/Gross weight: 1,1 kg/1,25 kg

Package size (L x W x H): 247 mm x 97 mm x 250 mm

Producer:

Cosmos Far View International Limited

Room 701, 16 apt, Lane 165, Rainbow North Street, Ningbo, China

Made in China

WARRANTY DOES NOT COVER SUPPLIES (filters, ceramic and non-stick coating, rubber seals, etc.)


Production date is available in the serial number located on the identification sticker on the gift box and/or on sticker on the device. The serial number consists of 13 characters, the 4th and 5th characters indicate the month, the 6th and 7th indicate the year of device production.

Producer may change the complete set, appearance, country of manufacture, warranty and technical characteristics of the model without notice. Please check when purchasing device.

Current information about service centers is available on the website <https://lumme-ru.com/>

LUMME

Documents / Resources

	<p>LUMME LU-SM1252B Nut Maker [pdf] User Manual LU-SM1252B, LU-SM1252B Nut Maker, Nut Maker</p>
--	---

References

-  [Интернет-магазин Lumme](#)