



LUTRON RA2 Select Main Repeater Hub User Guide

[Home](#) » [Lutron](#) » LUTRON RA2 Select Main Repeater Hub User Guide 



Quick-start guide

Contents

- [1 RA2 Select Main Repeater Hub](#)
- [2 Extend Your Warranty](#)
- [3 Install the RA2 Select Main Repeater](#)
- [4 Download the Lutron app and walk through setup](#)
- [5 Documents / Resources](#)

RA2 Select Main Repeater Hub


RA2 Select Main Repeater

Please read before installing Contents supplied:

RA2 Select Main Repeater*

(RR-SEL-REP2)

5V= 300 mA




Power Supply


(T-5DC-USB)

Input: 100-240 V~ 50/60 Hz 100 mA

Output: 5 V== 550 mA



Ethernet Cable




* Connected to a Class 2, LPS, or SELV, limited energy (<15 W) power source only.

Extend Your Warranty


Love Lutron products? Have ideas for making them better? Tell us what you think and we'll extend your warranty by 1 year. www.lutron.com/RegisterRA2Select

Install the RA2 Select Main Repeater

A. Connect the Main Repeater to your Wi-Fi router using the Ethernet cable.



B. Connect the power cord to the Main Repeater and plug it into an outlet.



Download the Lutron app and walk through setup



Search for "Lutron App"



Lutron

Note: The RA2 Select Main Repeater cannot be used with the RadioRA 2 PC-based programming software.

Accessory Setup Code

Warranty

For warranty information, please visit www.lutron.com/warranty



Lutron, Lutron, and  are trademarks of Lutron Electronics Co., Inc. registered in the U.S. and other countries. RadioRA 2 is a trademark of Lutron Electronics Co., Inc.

Apple is a trademark of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries. Google Play and the Google Play logo are trademarks of Google Inc.

©2017 Lutron Electronics Co., Inc.


Customer Assistance

 **LUTRON**
U.S.A. and Canada: 1.844.LUTRON1
Fax: +1.610.282.6311
Mexico: 1.888.235.2910
Other countries: +1.610.282.3800
www.lutron.com/support



0301866 Rev A

Documents / Resources



[LUTRON RA2 Select Main Repeater Hub](#) [pdf] User Guide

RR-SEL-REP2, RA2, RA2 Select Main Repeater Hub, Select Main Repeater Hub, Main Repeater Hub, Repeater Hub