



LUXPRO LP1035V2 High-Output Focusing Handheld Flashlight User Manual

[Home](#) » [LUXPRO](#) » LUXPRO LP1035V2 High-Output Focusing Handheld Flashlight User Manual 

Contents

- [1 LUXPRO LP1035V2 High-Output Focusing Handheld Flashlight](#)
- [2 Features](#)
- [3 Operation Instructions](#)
- [4 Battery Replacement](#)
- [5 Product Warranty](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)






LUXPRO LP1035V2 High-Output Focusing Handheld Flashlight



Features

- Constructed with aircraft-grade aluminum
- LPE optics
- Push/pull focus beam
- Patented TackGrip molded rubber grip
- High quality wrist lanyard
- Tactical on/off button
- IPX4 waterproof rating
- Batteries included (4 AAA)

ANSI/PLATO FL1 STANDARD			
			
MODES	LUMENS	RUN TIME	BEAM DISTANCE
High	570 lm	2h	275m
Medium	175 lm	6h	165m
Low	43 lm	22h	80m
Strobe	470 lm	--	--

Operation Instructions

On/Off: Press and release the button on the tail cap to turn the light on and off.



Cycle Modes: Press button on tail cap quickly to cycle through modes (High/Medium/Ultra-Low). If light remains in a single mode for longer than 3 seconds, the next press of the button will turn the light off. Light Automatically rests to High mode when turned off.

Hidden Strobe On/Off: Press and hold button for 3 seconds to activate hidden strobe. Flashlight will remain in hidden strobe mode until it is deactivated by pushing and holding the button for 3 seconds again.

Focus Head: To focus the light beam, gently push the head away from the light to extend it. Pull the head back towards the light to widen the beam.



Battery Replacement

The LP1035V2 uses 4 AAA batteries.

To replace the batteries, turn the tail cap counterclockwise to remove it. Tip the light downward to slide out the battery case which contains the batteries. Remove the batteries from the case and insert new batteries according to the (+/-) symbols found on the case. For best results, we recommend using brand new alkaline batteries that are the same voltage and brand.

Re-insert the battery case into the flashlight with the arrow on the battery case pointing down. Re-attach the tail cap by pressing down lightly and turning it clockwise until tight.



If you know it will be a while between uses, we suggest removing the batteries from the flashlight and storing it in a dry, protected place.

Product Warranty

The LP1035V2 has a Limited Lifetime Warranty Against Manufacturer's Defects from time of purchase. For warranty claims please contact us by calling 801-553-8886 or sending an email to

info@simpleproducts.com

luxpro.com

14725 S Porter Rockwell Blvd Ste C Bluffdale, UT 84065

Documents / Resources



[LUXPRO LP1035V2 High-Output Focusing Handheld Flashlight](#) [pdf] User Manual
LP1035V2, High-Output Focusing Handheld Flashlight