

LUXPRO LP1100BL High-Output Universal Large Flashlight User Manual

Home » LUXPRO » LUXPRO LP1100BL High-Output Universal Large Flashlight User Manual

Contents

- 1 LUXPRO LP1100BL High-Output Universal Large **Flashlight**
- 2 Features
- **3 Operation Instructions**
- 4 Usage and Maintenance
- **5 Product Warranty**
- 6 Documents / Resources
 - **6.1 References**
- 7 Related Posts



LUXPRO LP1100BL High-Output Universal Large Flashlight



Features

- Durable aluminum construction
- Long range LPE Optics
- Rubber grip
- · Heavy duty flashlight
- Ergonomic side button
- O-ring sealed, IPX5
- 3 Modes: High/Low/Strobe

Operation Instructions

- 1. On/Off: Press and release button.
- 2. Cycle modes: From High mode, half-press button to cycle through modes (High/Low/Strobe).
- 3. Automatically resets to High mode when off for longer than 5 seconds.

Usage and Maintenance

Battery Replacement: In a dry environment, unscrew the tailcap by turning counter clockwise. Remove batteries. Insert the new batteries into the tube (+) end first. Carefully reinstall the tailcap by pressing lightly while turning clockwise.

Care Instructions: If you know it's going to be a while between uses, we suggest removing batteries from your light and storing your gear in a dry, protected place.



	ANSI/PLATO FL1 STANDARD			
	31/5	(1)	REAM	
MODES	LUMENS	RUN TIME	BEAM DISTANCE	
High	320lm	7h	250 m	
Low	120 lm	5 h	100 m	
Strobe	320lm		P)	

Product Warranty

Limited Lifetime Warranty against manufacturer's defects. For warranty claims contact LuxPro by calling 801-553-8886 or sending an email to info@simpleprod-ucts.com.

luxpro.com

866.553.8886

14725 S Porter Rockwell Blvd Ste C Bluffdale, UT 84065

Documents / Resources



LUXPRO LP1100BL High-Output Universal Large Flashlight [pdf] User Manual LP1100BL, High-Output Universal Large Flashlight, LP1100BL High-Output Universal Large Flashlight

References

- <u>LUXPRO Flashlights</u>
- Qucts.com

Manuals+,