



LUXPRO LP1200V2 High-Output Large Flashlight User Manual

[Home](#) » [LUXPRO](#) » LUXPRO LP1200V2 High-Output Large Flashlight User Manual 

Contents

- [1 LUXPRO LP1200V2 High-Output Large Flashlight](#)
- [2 Features](#)
- [3 ANSI/PLATO FL1 STANDARD](#)
- [4 Operation Instructions](#)
- [5 Battery Replacement](#)
- [6 Product Warranty](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



LUXPRO LP1200V2 High-Output Large Flashlight



Features

- Constructed with aircraft-grade aluminum
- Long range LPE optics
- Patented TackGrip rubber grip Ergonomic side button
- IPX4 waterproof rating
- Uses 6 AA or 3 AA batteries (6 AA included)

ANSI/PLATO FL1 STANDARD

ANSI/PLATO FL1 STANDARD			
MODES	LUMENS	RUN TIME	BEAM DISTANCE
High	775 lm	7h	300m
Medium	324 lm	17h	220m
Low	61 lm	92h	40m
Strobe	775 lm	--	--

Operation Instructions



Cycle Modes: Press button on side of the light quickly to cycle through modes (High/Medium/Low). If light remains in a single mode for longer to 3-5 seconds, the next press of the button will turn the light off. Light automatically resets to High mode when turned off.


Hidden Strobe On/Off: Press and hold button for 3 seconds to activate hidden strobe. Flashlight will remain in hidden strobe mode until it is deactivated by pushing and holding the button for 3 seconds again.

Battery Replacement


The LP1200V2 can use 6 or 3 AA batteries. To replace the batteries, turn the tail cap counterclockwise to remove it. Tip the light downward to slide the batteries out of the tubes.



To use the light with 6 batteries, insert 3 batteries into each tube (+) side first (batteries will stick out of the opening slightly).



To use the light with 3 batteries, insert 3 batteries into just one of the tubes (+) side first.



For best results, we recommend using brand new alkaline batteries that are the same voltage and brand. Re-attach the tail cap by pressing down and turning it clockwise until tight. If you know it will be a while between uses, we suggest removing the batteries from the flashlight and storing it in a dry, protected place.

Product Warranty

The LP1200V2 has a Limited Lifetime Warranty Against Manufacturer's Defects from time of purchase. For warranty claims please contact us by calling 801-553-8886 or sending an email to info@simpleproducts.com

Documents / Resources



[LUXPRO LP1200V2 High-Output Large Flashlight](#) [pdf] User Manual
LP1200V2, High-Output Large Flashlight