

LUXPRO LP1201 High-Output LED Flashlight User Manual

Home » LUXPRO » LUXPRO LP1201 High-Output LED Flashlight User Manual





Contents

- 1 Features
- **2 Operation Instructions**
- 3 Battery Replacement
- **4 Product Warranty**
- **5 Documents** /
- **Resources**
- **6 Related Posts**

Features

Constructed with aircraft-grade aluminum
Long range LPE optics
Patented TackGrip rubber grip
Ergonomic side button
IPX4 waterproof rating
Uses 6 AA or 3 AA batteries (6 AA included)

ANSI/PLATO FL1 STANDARD

	31/2	()	
MODES	LUMENS	RUN TIME	BEAM DISTANCE
High	1000 lm	6h	400m
Medium	380 lm	18h	220m
Low	80 lm	67h	100m
Strobe	1000 lm	_	_

Operation Instructions

On/Off: Press and release the button on the side of the light to turn on and off.



Cycle Modes: Press the button on the side of the light quickly to cycle through modes (High/Medium/Low). If light remains in a single mode for longer to 3-5 seconds, the next press of the button will turn the light off. Light automatically resets to High mode when turned off.

Hidden Strobe On/Off: Press and hold button for 3 seconds to activate hidden strobe. Flashlight will remain in hidden strobe mode until it is deactivated by pushing and holding the button for 3 seconds again.

Battery Replacement

The LP1201 can use 6 or 3 AA batteries.

To replace the batteries, turn the tail cap counterclockwise to remove it. Tip the light downward to slide the batteries out of the tubes.



To use the light with 6 batteries, insert 3 batteries into each tube (+) side first (batteries will stick out of the opening slightly).

 \bot To use the light with 3 batteries, insert 3 batteries into just one of the tubes (+) side first.

For best results, we recommend using brand new alkaline batteries that are the same voltage and brand. Reattach the tail cap by pressing down and turning it clockwise until tight.

If you know it will be a while between uses, we suggest removing the batteries from the flashlight and storing it in a dry, protected place.

Product Warranty

The LP1201 has a Limited Lifetime Warranty Against Manufacturer's Defects from time of purchase. For warranty claims please contact us by calling 801-553-8886 or sending an email to info@simpleproducts.com

luxpro.com

866.553.8886 14725 S Porter Rockwell Blvd Ste C Bluffdale, UT 84065

Documents / Resources



LUXPRO LP1201 High-Output LED Flashlight [pdf] User Manual

LP1201, High-Output LED Flashlight, LED Flashlight, Flashlight, LP1201 High-Output LED Flashlight

Manuals+,