



# LUXPRO LP345 Multi-function LED Headlamp with Red and Green Flood Modes Instruction Manual

[Home](#) » [LUXPRO](#) » LUXPRO LP345 Multi-function LED Headlamp with Red and Green Flood Modes Instruction Manual 

## Contents

- [1 LUXPRO LP345 Multi-function LED Headlamp with Red and Green Flood Modes](#)
- [2 Features](#)
- [3 Product Warranty](#)
- [4 ANSI/PLATO FL1 STANDARD](#)
- [5 Operation Instructions](#)
- [6 Battery Replacement](#)
- [7 Documents / Resources](#)
- [8 Related Posts](#)



**LUXPRO LP345 Multi-function LED Headlamp with Red and Green Flood Modes**






**Features**

- Durable ABS and rubberized compact design High efficiency LED
- Dual button operation
- Non-slip adjustable headband, optional dual strap 90° adjustable head
- IPX4 waterproof rating
- Batteries included (3 AAA)

## Product Warranty

The LP345 has a Limited 90-Day Warranty Against Manufacturer's Defects from time of purchase. For warranty claims please contact us by calling 801-553-8886 or sending an email to [info@simpleproducts.com](mailto:info@simpleproducts.com)

## ANSI/PLATO FL1 STANDARD

MODES	 LUMENS	 RUN TIME	 BEAM DISTANCE
High	<b>Spot Modes</b> 210 lm	6h	80m
Low	72 lm	16h	28m
Strobe	210 lm <b>Flood Modes</b>	—	—
White	15 lm	26h	6m
Green	9 lm	26h	3m
Red	2 lm	26h	1m

## Operation Instructions

**Spot On/Off & Cycle Modes:** Press and release the button on the right of the headlamp to turn spotlight on. Press button repeatedly to cycle through Modes (Spot High/Spot Low/Strobe).



**Flood On/Off & Cycle Modes:** Press and release the button on the left of the headlamp to turn flood light on. Press button repeatedly to cycle through modes (White/Green/Red).



## Battery Replacement

**The LP345 uses 3 AAA batteries.**

To replace the batteries, first locate the plastic tab on the top of the headlamp. Gently push the tab up and outward using your thumb to pop the battery cover loose and open it. Remove the old batteries and insert new batteries according to the (+/-) symbols in the battery tubes. For best results, we recommend using brand new alkaline batteries that are the same voltage and brand.

To re-attach the battery cover, press the headlamp housing and battery cover together until it clicks into place. Check that the battery cover is secured by gently tugging on the headlamp straps while holding the main housing firm.



If you know it will be a while between uses, we suggest removing the batteries from the headlamp and storing it in a dry, protected place.

Website: [luxpro.com](http://luxpro.com)

Tel: 866.553.8886

Address: 14725 S Porter Rockwell Blvd Ste C Bluffdale, UT 84065

## Documents / Resources



[LUXPRO LP345 Multi-function LED Headlamp with Red and Green Flood Modes](#) [pdf] Inst

ruction Manual

LP345 Multi-function LED Headlamp with Red and Green Flood Modes, LP345, Multi-function L  
ED Headlamp with Red and Green Flood Modes, Red and Green Flood Modes, LED  
Headlamp, Headlamp

[Manuals+](#)