



LXJADAP HDMI Wireless Transmitter and Receiver Instructions

[Home](#) » [LXJADAP](#) » LXJADAP HDMI Wireless Transmitter and Receiver Instructions 



HDMI Wireless Transmitter and Receiver Instructions

Contents


- [1 HDMI Wireless Transmitter and Receiver](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)

HDMI Wireless Transmitter and Receiver

If the light of TX keeps flashing after plugging TX / RX into the corresponding device, it means that TX and RX are not paired.

Please follow the steps below to re-pair;

1. Use a sharp tool (such as a card pin, toothpick or others that can enter the hole) to insert into the hole of the TX port (there is a button in the hole), make sure to press the button successfully, After about 7-10s of pressing, the light will disappear briefly, You can stop this operation at this time.



Card Pin

2. Use a sharp tool (such as a card pin, toothpick or others that can enter the hole) to insert into the hole of the RX port (there is a button in the hole), make sure to press the button successfully, Watch the TV screen while pressing the button, Release the button when this text appears when this text appears. "Release the button to pair with Mate TX"




3. After this text, Will appear a "QR code(Ready to pair)" then shows "pairing..." and finally shows "pair ok"
(**Note:** If the QR code still does not appear, please repeat the above two steps.)



4. Pairing successful.



Documents / Resources

	<p>LXJADAP HDMI Wireless Transmitter and Receiver [pdf] Instructions HDMI Wireless Transmitter and Receiver, Wireless Transmitter and Receiver, Transmitter and Receiver, Receiver</p>
---	--

References

- [User Manual](#)