


BESTÅ



Design and Quality
IKEA of Sweden



English

WARNING

Children have died from furniture tipover. To reduce the risk of furniture tipover:

ALWAYS install anti-tip device provided.

NEVER put a TV on this product.





NEVER allow children to stand, climb, or hang on any drawers, doors, or shelves.











NEVER open more than one drawer at a time.

Place heaviest items in the lowest drawers.


English

Read and follow each step of the instruction carefully.







1




2




3




4




5








6









8









10




2x






CLICK!








11









13



2x





CLICK!



133194
133195
133196
133303
133304
126918




1



4x

116637 114929

2



4x

113301

