



Original	Recharge	Original	Recharge
STEP	Step	ANGLE	Angle
SEARCH	Search	INFO	Info / Angle
MUTE	Mute	LANG / III	Audio / Lang I / II
SOURCE	Source	AUDIO	Audio
1	1	MENU / PBC	Menu / Home
2	2	TITLE	Sound / Title
3	3	Up	Up
4	4	Stop	Stop / Hold
5	5	Play	Play / Slow
6	6	Left	Left
7	7	Enter	OK
8	8	Right	Right
9	9	MODE	Smart / List
0	0	MODE	Pause / Step / Freeze
10+	10+	SETUP	Set up / OPT /
DISPLAY	Display	Down	Down
SUBTITLE	Subtitle	VOL -	Vol -
		VOL +	Vol +
		REPEAT	Green / APP / Repeat



