




折页尺寸：120X68mm

正面

<p>Bobtot®</p> <p>User Manual</p> <p>Portable Speaker with Microphone ET29</p>	<h3>Packing List</h3> <ul style="list-style-type: none"> User Manual 3.5mm Audio Cable Type-c Charging Cable Microphone 	<h3>Button Function</h3> <ol style="list-style-type: none"> Power Indicator Volume down / Previous song Karaoke mode switch & Light on/off Play/pause EQ mode Power Volume up / Next song Type-S Slot (charge only) TF card Slot AUX Slot (3.5mm Audio jack) USB Slot RST (Reset Slot) 	<h3>Button Function description</h3> <table border="1"> <thead> <tr> <th>Button</th> <th>Key Operation</th> <th>Function Description</th> </tr> </thead> <tbody> <tr> <td rowspan="3"></td> <td>Short press</td> <td>Increase the volume</td> </tr> <tr> <td>Long press</td> <td>Next song</td> </tr> <tr> <td>Short press</td> <td>Short press to switch between BT/AUX/USB/TF card mode</td> </tr> <tr> <td rowspan="3"></td> <td>Long press</td> <td>Press and hold for 3 seconds to turn on/off</td> </tr> <tr> <td>Short press</td> <td>Short press to switch Indoor/Outdoor mode</td> </tr> <tr> <td>Short press</td> <td>Play/Pause</td> </tr> <tr> <td rowspan="3"></td> <td>Long press</td> <td>Disconnect BT</td> </tr> <tr> <td>Short press</td> <td>Decrease the volume</td> </tr> <tr> <td>Long press</td> <td>Previous song</td> </tr> <tr> <td rowspan="3"></td> <td>Short press</td> <td>Karaoke mode/Vocal mode/KTV mode</td> </tr> <tr> <td>Double click</td> <td>Light on/off</td> </tr> </tbody> </table>	Button	Key Operation	Function Description		Short press	Increase the volume	Long press	Next song	Short press	Short press to switch between BT/AUX/USB/TF card mode		Long press	Press and hold for 3 seconds to turn on/off	Short press	Short press to switch Indoor/Outdoor mode	Short press	Play/Pause		Long press	Disconnect BT	Short press	Decrease the volume	Long press	Previous song		Short press	Karaoke mode/Vocal mode/KTV mode	Double click	Light on/off	<h3>How To Use The Speaker</h3> <ul style="list-style-type: none"> ✓ Wireless BT connection <ul style="list-style-type: none"> • Short press button, the speaker enters the BT mode, the blue light of the power button icon flashes quickly to enter the pairing state, and search for your BT device named "Bobtot ET29" and tap to connect. • When switching to BT mode again, you can double-click the button to play the song. ✓ TF card/U disk/Aux-in mode <ul style="list-style-type: none"> • Insert the TF card into the card slot or insert the U disk slot, the Bobtot ET29 portable speaker will automatically play music! (The max capacity is 64Gb for TF card or U disk, it can be recognized by the speaker). • Connect any audio device with a 3.5mm cable for playing ✓ Charing (Type-C) <ul style="list-style-type: none"> • Insert one end of the charging cable into the USB interface, and connect the other end to the charging device to automatically enter the charging mode. 	
Button	Key Operation	Function Description																																
	Short press	Increase the volume																																
	Long press	Next song																																
	Short press	Short press to switch between BT/AUX/USB/TF card mode																																
	Long press	Press and hold for 3 seconds to turn on/off																																
	Short press	Short press to switch Indoor/Outdoor mode																																
	Short press	Play/Pause																																
	Long press	Disconnect BT																																
	Short press	Decrease the volume																																
	Long press	Previous song																																
	Short press	Karaoke mode/Vocal mode/KTV mode																																
	Double click	Light on/off																																
	1	2	3	4	5	6																												

反面

<h2>How to Use Microphone</h2> <p>Turn On/Off When the ET29 speaker is on, press the  button of the microphone for 2 seconds to turn on, the indicator light is green, which is automatically connected to the ET29 speaker, and you can sing the song now. Press  for 2 seconds to turn it off.</p> <p>Volume Up/Down Short press microphone - / + to reduce/increase the microphone volume.</p> <p>Adjust the Mode When you are singing the song, short press the  button in the ET29 speaker, you can switch to karaoke mode, vocal mode, KTV mode to enjoy different scene sound effects.</p> <p>Charging Plug the USB Type-C into the charging port of the microphone, the indicator light is red. When the microphone is fully charged the red light will be off. Full charge the battery is about 1-2 hours.</p> <p>Note: The ideal distance between the microphone and the ET29 speaker is ≥10 meters.</p>	<h2>Specifications</h2> <table border="1"> <thead> <tr> <th>Describe</th><th>Specifications</th><th>Describe</th><th>Specifications</th></tr> </thead> <tbody> <tr> <td>Model Name</td><td>Bobtot ET29</td><td>Charging Voltage</td><td>5V2A</td></tr> <tr> <td>Transmission Distance</td><td>≥ 10m (Open Field)</td><td>Charging Time</td><td>4-6H</td></tr> <tr> <td>Peak Power Output</td><td>60W</td><td>Frequency Response</td><td>60hz~18Khz</td></tr> <tr> <td>Local Decoding</td><td>Support MP3/FLAC/APE/WMA</td><td>Waterproof Level</td><td>IPX7</td></tr> <tr> <td>Speaker Size</td><td>2"66mm</td><td>BT Version</td><td>Wireless 5.1</td></tr> <tr> <td>Product Size</td><td>250*104*104mm</td><td></td><td></td></tr> </tbody> </table>	Describe	Specifications	Describe	Specifications	Model Name	Bobtot ET29	Charging Voltage	5V2A	Transmission Distance	≥ 10m (Open Field)	Charging Time	4-6H	Peak Power Output	60W	Frequency Response	60hz~18Khz	Local Decoding	Support MP3/FLAC/APE/WMA	Waterproof Level	IPX7	Speaker Size	2"66mm	BT Version	Wireless 5.1	Product Size	250*104*104mm			<h2>Kindly reminder</h2> <ul style="list-style-type: none"> Please keep the microphone at least 20cm away from the speaker. Please check the chargerspecifications before charging, do not use fast charging or high voltage chargers to charge the speaker. For hearing health, please do not use it at maximum volume for a long time. Do not use it near a fire source or in a high temperature environment to avoid permanent damage to the speaker. Please use it strictly in accordance with the instructions, and do not modify or disassemble the product without permission. Do not drop, impact, knock, squeeze or other behaviors that seriously affect the product structure to avoid damage to the strength and reliability of the product. If you encounter high temperature, deformation, corrosion and other abnormalities during use, please stop using it immediately and contact the merchant for proper disposal. 	<h2>FCC Requirement</h2> <p>Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p>	<ul style="list-style-type: none"> – Reorient or relocate the receiving antenna. – Increase the separation between the equipment and receiver. – Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. – Consult the dealer or an experienced radio/TV technician for help. <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>	<p>Time We understand that our customers' time is valuable, so we will respond to any inquiries within 24 hours.</p> <p>Feedback We know that our customers are the heart of our business so we value your feedback. We encourage you to share your thoughts and ideas with us.</p> <p>Solutions If our customers encounter any issues, we will try our best to find a quick and efficient solution that meets your needs. Here at Bobtot, we take customer care very seriously. Our customers are our first priority, and we are committed to providing the highest quality service. If you have any questions or concerns, please don't hesitate to reach out to us.</p> <p>We will be happy to assist you: Call or Message: +1 888 572 1718 Email: service@bobbtot.net</p> <p>bobbtot.net</p> <p>2023 BOBTOT/Features and specifications are subject to change and or improvement without notice.</p>
Describe	Specifications	Describe	Specifications																														
Model Name	Bobtot ET29	Charging Voltage	5V2A																														
Transmission Distance	≥ 10m (Open Field)	Charging Time	4-6H																														
Peak Power Output	60W	Frequency Response	60hz~18Khz																														
Local Decoding	Support MP3/FLAC/APE/WMA	Waterproof Level	IPX7																														
Speaker Size	2"66mm	BT Version	Wireless 5.1																														
Product Size	250*104*104mm																																
6	5	4	3	2	1																												

技术要求:

1. 成品尺寸120*68mm
2. 128g铜版纸
3. 风琴折
4. 黑色单色印刷

深圳市恩科电子有限公司						SHENZHEN CITY ENKOR ELECTRONICS LTD					
设计绘图	测试员	品质经理	业务经理	产品经理	研发经理	客户品牌	内部型号	零件名称	材 料	单 位	版本
										MM	1.2
料 号				部 门		研发部	PMC	采购部	品管部	木箱部	生产部
BZ0-ET29SMSB01						✓		✓	✓		✓