UNDERCARRIAGE

TOP

TOP

Ø24 [Ø$\frac{15}{16}$]

Ø6 [Ø$\frac{1}{4}$]

CROSS MEMBER

Ø7 [Ø$\frac{9}{32}$]

Ø24 [Ø$\frac{15}{16}$]

Ø6 [Ø$\frac{1}{4}$]

Ø7 [Ø$\frac{9}{32}$]

Ø24 [Ø$\frac{15}{16}$]

Ø6 [Ø$\frac{1}{4}$]

Ø7 [Ø$\frac{9}{32}$]

INSTRUCTIONS TO PRINT PDF TO
ACTUAL SIZE:
1. Open PDF in Adobe Acrobat Aplication
(Its free)
2. Click on File>>Print.
3. Under Page Size & Handling check the
Actual size option.
4. Click on Print to print the document.
5. Meassure the 6" line on the right to
ensure the print is an accurate size.

152.4 [6]