primo

MINI/MIDI

CHECK & INSTALL SOFTWARE

westomatic
*make it happen*

CHECK THE SOFTWARE

1 Select the Menu Button

2 Select the Analysis Button

3 Press the ⟶ button 3 times.

4 MACHINE INFORMATION:

SOFTWARE VERSION: V...

LAST SOFTWARE UPDATE: date shown

INSTALL NEW SOFTWARE

1 Download the software onto the SD Card, and install into the machine.

2 All the Recipe settings and personal preferences are preserved during the software update.

3 You will need:

- Internet Connection and access to WVS website
- Computer with SD slot
- SD Card

4 How to prepare SD Card:

Download software for relevant machine - open ZIP file and copy **ALL Folders** and **Files**

📁 standard
📁 system
📄 blacklist.txt
📄 OVT_1.3.1502.bin
📄 Version 1.3.txt

5
- Open the rubber cover
- Insert SD Card - golden contacts towards you

6 Select 08 SOFTWARE

SERVICE MENU (2.0)

01	INGREDIENTS
02	RECIPES
03	SETTINGS
04	COUNTERS
05	SERVICE
06	HARDWARE
07	READ AND REMOVE LOG
08	SOFTWARE
09	CHANGE PIN CODES
10	CLEANING

BACK   INFO   SAVE

7 Select 01 LOAD DATA / SOFTWARE

SOFTWARE (2.8)

01	LOAD DATA / SOFTWARE
02	SAVE DATA
03	LOGGING TO SD-CARD
04	FILESYSTEM CLEAN-UP

BACK   INFO   SAVE

8 Select 04 SOFTWARE UPDATE

LOAD DATA / SOFTWARE (2.8.1)

| 01 | PERSONAL SETTINGS |
02	RECIPE
03	LANGUAGE
04	SOFTWARE UPDATE
05	LOAD OTHER VARIANT
06	LOAD DEFAULT VALUES
07	LOAD OTHER MODEL

BACK   INFO   SAVE

9 Confirm with **YES** to start the software update

10 Software update starts:
Updating - system files/media files/model files/translations/mainprint/firmware
Machine restarts

11
- Remove SD Card
- Close the rubber door

12 To check the software:
Select Menu button
Select **ANALYSIS**

13 Press the ⟶ button 3 times.

14 MACHINE INFORMATION:

SOFTWARE VERSION: V...

LAST SOFTWARE UPDATE: date shown

primo

westomatic
British Vending Excellence Since 1966