




Combination keys / Tastenkombinationen / Комбинация клавиш / Teclas de combinação

Presentación de las combinaciones de teclas / Kombinationstangent-introduktion

Fn + F1	Fn + F6 / F8	Fn + < / F11	Fn + ↓	Fn + P	F3
Fn + F2	Fn + F7 / F7	Fn + > / F12	Fn + ↑	Fn + I	F4
Fn + F3	Fn + F8 / F9	Fn + L	Fn + ←	Fn + W	
Fn + F4	Fn + C	Fn + -	Fn + →	F1	
Fn + F5	Fn + M / F10	Fn + =	Fn + U	F2	

Fn+right Ctrl=Press and hold for 3s to switch to MENU key (memorable), hold again to revert. Fn+Rechts-Strg=3s halten für Menütaste (speicherbar), erneut halten zum Zurücksetzen.. Fn+правый Ctrl=Нажмите и удерживайте в течение 3 секунд для смены на клавишу MENU (запоминается), удерживайте снова для возврата.	Fn+Ctrl derecho:Mantenga presionadas durante 3 segundos para cambiar a la tecla de menú , luego mantenga presionadas para volver. Fn+höger Ctrl:Håll ned i 3 sekunder för att växla till meny tangent, håll ned igen för att återgå
Fn+left Ctrl=Toggle through 10 side light effects, including off. Fn+Links-Strg=Seitenbeleuchtungsmodus wechseln, inkl. Aus (10 Modi). Fn+левый Ctrl=Переключение между 10 режимами боковой подсветки, с читая выключение. Fn+Ctrl esquerdo=Alternar entre 10 efeitos de luz lateral, incluindo o modo desligado.	Fn+Ctrl izquierdo=Cambiar el modo de luz lateral, un total de 10 tipos, incluido el apagado. Fn+vänster Ctrl=Växla sidobelysningsläge, inklusive avstängning, totalt 10 lägen.
Knob Function: Press the knob to mute. Rotate counterclockwise to decrease the volume or clockwise to increase it. Funktion des Drehknopfs: Durch Drücken des Rads allein wird die Stummschaltung aktiviert. Gegen den Uhrzeigersinn für Lautstärke -, im Uhrzeigersinn für Lautstärke +. Функция ручки: однократное нажатие на колесико отключает звук. Пр отив часовой стрелки для громкости -, по часовой стрелке для громко	СТИ. Função do botão: Pressionar o botão sozinho é a função de mudo. No sentido anti-horário para o volume -, no sentido horário para o volume +. Función de la rueda: Pulsar la rueda sola es la función de silencio. En sentido antihorario para volumen -, en sentido horario para volumen +. Función de la rueda: Pulsar la rueda sola es la función de silencio. En sentido antihorario para volumen -, en sentido horario para volumen +.

((BT))

Bluetooth Pairing / Bluetooth-Kopplung / Сопряжение по Bluetooth / Emparelhamento Bluetooth

Emparejamiento Bluetooth / Bluetooth-parning

After powering on the keyboard, press Fn + E/R/T to enter Bluetooth mode.Nach dem Einschalten der Tastatur, Fn+E/R/T für Bluetooth-Modus drücken. После включения клавиатуры нажмите Fn+E/R/T, чтобы перейти в режим Bluetooth.Após ligar o teclado, pressione Fn+E/R/T para entrar no modo Bluetooth.Después de encender el teclado, presione Fn+E/R/T para ingresar al modo Bluetooth. para ingresar al modo Bluetooth.Efter att tangentbordet startas, tryck på Fn+E/R/T för att gå in i Bluetooth-läge.

2.4G


2.4G Pairing / 2.4G-Kopplung / Сопряжение 2.4G / Emparelhamento 2.4G / Emparejamiento 2.4G / 2.4G-parning

After powering on the keyboard, press Fn+Y to enter 2.4G mode. Nach dem Einschalten, Fn+Y für 2.4G-Modus drücken. После включения клавиатуры нажмите Fn+Y, чтобы перейти в режим 2.4G. Após ligar o teclado, pressione Fn+Y para entrar no modo 2.4G. Después de encender el teclado, presione Fn+Y para ingresar al modo 2.4G. Efter att tangentbordet startas, tryck på Fn+Y för att gå in i 2.4G-läge.

Battery-Level Check/ Akkustand-Anzeige / Проверка уровня заряда батареи / Verificação do Nível da Bateria

Consulta de estado de carga de batería / Batterinivåkontroll

After powering on the keyboard, press Fn+Spacebar to Battery Check. Nach dem Einschalten, Fn+Leertaste für 2Akkustand prüfen drücken. После включения клавиатуры нажмите Fn+Пробел, чтобы перейти в режим Проверка уровня заряда батареи. Após ligar o teclado, pressione Fn+Barra de Espaço para entrar no modo Verificação da Bateria. Después de encender el teclado, presione Fn+Espacio para ingresar al modo Consulta de estado de carga de la batería. Efter att tangentbordet startas, tryck på Fn+Mellanslag för att gå in i Kontrollera batterinivå.



Indicator / Anzeigen / Световые индикаторы / Indicador / Luz indicadora / Indikatorlampor

	○Indicator○Indikator ○Индикатор○Indicador	○Reconnecting ○Wiederherstellung der Verbindung○Повторное по дключение○Reconectando ○Volver a conectar ○Återanslutning	○Pairing○Paarung○Парная работа○Emparelhando ○Emparejamiento ○Parring	○Successfully Connected ○Erfolgreich verbunden○Успе шно подключено○Conectado com Sucesso○Conectado con éxito○Framgångsrikt ansluten		○Indicator○Anzeigen ○Indicador○Световые ин дикаторы○Indicador○Luz indicadora○Indikatorlampor	○Estado do LED○LED-Status ○Состояние светодиодов ○Status do LED○Estado del LED○LED-status
BT1	E	Red	Red	Red		LED2	Red
BT2	R	Blue	Blue	Blue		LED2	Red
BT3	T	Yellow	Yellow	Yellow		LED2	
	Y	Green	Green	Green	Caps	LED1	White
	U			White		LED3	White

www.akkogear.com

Key/Lighting Effects Customization Instruction

VIA is a widely recognized software that offers an intuitive interface for configuring and personalizing various keyboard settings. Users can utilize VIA to remap keys and adjust lighting on keyboards with VIA firmware.

Web Version: <https://usevia.app/>

App: <https://github.com/the-via/releases/releases>

It enables you to remap keys, create custom macros, customize lighting effects, and more. If you encounter connection issues, please load the corresponding JSON file specific to your keyboard model.

You can download JSON files from our dedicated Download page:

<https://en.akkogear.com/download/>

<https://akkogear.eu/pages/download-center>

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

FCC-ID: 2A4K8-5075B

RF warning statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

AKKO Warranty and Service Statement

1. Akko provides One-Year warranty for customers in mainland China. For other regions, please contact your seller (Akko distributor) for specific warranty policy.

2. If the warranty window expires, customers need to pay for repairs. Akko will also provide instructions if users prefer to repair the keyboard by themselves. However, users shall take full responsibility for any loss happened during self-repair.

3. Defects resulting from disassembly of our product, improper usage and incorrect installation are not covered by warranty.

4. The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.

EU DECLARATION OF CONFORMITY	
This declaration of conformity is issued under the sole responsibility of the manufacturer.	
(Manufacturer and EC Responsible Person Information)	
Manufacturer	
Company Name	Shenzhen Yinchen Technology Co., Ltd
Address	Bitou Community 1st Industrial Zone, Building 1STE 101, 201, 301, 401
Email	Emily@akkogear.com
Telephone	0755-23216420
Product Information	
Product Name	Mechanical Keyboard
Model	5075B
Trade Mark	Akko
The object of the declaration described above is in conformity with the relevant Community harmonisation legislation / EC directives:	
EC directives	
RED Directive 2014/53/EU and LVD Directive 014/35/EU & EMC Directive 2014/30/EU	
Testing Standards	
EN IEC 62368-1:2020+A11:2020 EN 50663: 2017; EN 62479: 2010 ETSI EN 301 489-1 V2.2.3 (2019-11) ETSI EN 301 489-17 V3.2.4(2020-09) ETSI EN 500 328 V2 2.2 (2019-07)	
(Signed on behalf of the Manufacturer)	
Signature:	Name: Wu Haiyan
	Position: Vice president
	Date: Emily@akkogear.com



Disposal

The symbol above and on the product means that the product is classed

as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The Waste of Electrical and Electronic Equipment (WEEE) Directive has been put in place to recycle products using best available recovery and recycling techniques to minimize the impact on the environment treat any hazardous substances and avoid the increasing landfill. Contact local authorities for information on the correct disposal of Electrical or Electronic equipment.

It is forbidden to reproduce any part of this quick start guide without the permission of

Shenzhen Yinchen Technology Co., Ltd

Tel: 0755-23216420

Website: <https://en.akkogear.com/download/>

<https://akkogear.eu/pages/download-center>

Address: 33 Langbi Rd, Bitou First Industrial Zone,

Bao'an District, Shenzhen, China

Implementation Standard: GB/T 14081-2010

Made in China



Radio Equipment Directive 2014/53/EU
Frequency Bands: 2402MHz—2480MHz
Maximum Radio Frequency Power Transmitted: 10dB