

# ChunHee

## Wireless Intercom Manual

Model: HI05

Unlimited Communication, Unlimited Life!

### Intercom Wireless for Home



## Features

- \* Full Duplex
- \* Long Standby Time
- \* 5 Ringtones Available
- \* Adjustable Volume
- \* 1640ft Working Range
- \* Type-C Charge Port
- \* Rechargeable Battery
- \* Low Battery Alert
- \* Clear & Loud Voice

## Instruction

The ChunHee HI05 Wireless Intercom is a simple and secure way to communicate between multiple intercoms within an area of up to 1,640ft (500m).

- \* **Please read this manual thoroughly. It will help us to know how to use this intercom system and make the operation easier.**
- \* **The intercom contains non-repairable parts. Opening them may damage sensitive components and will void the warranty.**

## Parts List



Intercom



Charge Station



USB Cable



Charge Adapter



User's Manual

**\* The product does not include lanyards and screws.**

## Specification

Technology	Full Duplex
Frequency	2404-2480 MHZ
Output Power	2 W
Channel Quantity	1
Battery Cell Composition	Lithium Polymer
Battery Capacity	1000mAh
Working Range	500 Meters i.e. 1640ft
Weight	95g
Standby Time(Fully Power)	72-96 Hours
Operating Temperature	-20°F -140°F
Chimes Quantity	5 Chimes
Volume Levels	8 Levels
Size	9.4*5.4*14.6cm(Including Charging Seat)

**\* Actual working range may vary depending on the installation and operating environment**


## Overview




- ① Antenna
- ② Lanyard Hole
- ③ Speaker
- ④ Volume Decrease
- ⑤ Volume Increase
- ⑥ Power
- ⑦ Hang Up
- ⑧ Call/Answer
- ⑨ Indicator
- ⑩ Mic
- ⑪ Charge Port
- ⑫ Lanyard Hole
- ⑬ Wall-mount Hole
- ⑭ Anti-slip Pad

## Basic Operate



### ① Turn ON/OFF

Turn ON: Hold the  button for 5 seconds till hear "Power On" to release.



Turn OFF: Hold the  button for 5 seconds till hear "Power OFF" to release.



### ② Volume Change

**When the intercom on the ringing or calling status:** Press the  to decrease the volume, Press the  to increase the volume levels.


\* There are 8 volume levels available, you will hear a "Do" voice prompt sound when you press the  or  if the volume level is on the 1 (Min.) or 8 (Max.) level.

### ③ Intercom Pair

Hold the  and  buttons at the same time on the one intercom for 5 seconds till hear a "Searching" voice prompt to release.

Hold the  and  buttons at the same time on the other intercom that you need to connect for 5 seconds till hear a "Successful" voice prompt to pair.

### ④ Change the Ringtone


Hold the  button for 5 seconds until hear the ringtone to release the button to change the ringtone of the intercom (5 Chimes available).


\***Note:** You will hear a beep sound at first, but please keep holding the button till hear a ringtone sound to release.

## Basic Operate

### ⑤ Talk

Like a phone use:

Step 1: Press the  to calling the person you wanna talk with.

Step 2: The person you called press the  to answer you. Then both of you can talk with each other.

Step 3: Press the  button to finish the calling.

## Video Guide



## Indicator

### \* Charging Status:

- 1) Turn off status: Red color while charging.
- 2) Turn on status: Red color and with flashes blue color every 5 second.

**Note: The light will goes out while fully charged.**

\* Standby Status: Blue color flashes every 5 seconds.

## Low Battery Alert

On a full charge, the standby time of the intercom is about 72-96 Hours. (Please charge the intercom before first use.)

There has a low battery alert while the radio is low battery, it will send a voice prompt every 20 seconds until it is turned off. (If the radio runs out of power and turns off, turn it on when fully charged.)

## Warm Tips

- \* The microphone will beep while the device is within 1 meter. Please don't worry about it, just need to separate them from each other.
- \* We suggest to place the product into the charge station to charge, it will protect the intercom.
- \* The intercom system does have not a waterproof design, please take the product away from water.
- \* The intercom system is powered by battery, please Do not place the the product in a flammable or explosive environment.

## Troubleshooting

### **Q1: Can't turn on the intercom.**

- A1:** 1) Charge for the intercom at least 1 hour.  
2) Wait 5 seconds then hold the power button for 5-8s till hear 'Power On' voice prompt.

### **Q2: The voice is weak or intermittent during receiving.**

- A2:** 1) Recharge the battery.  
2) Increase the volume level.

### **Q3: Can't communicate with other intercom**

- A3:** 1) Pair for the intercom.  
2) All intercoms press the hang up button to stop talk, then one of the intercom press the Green Call button to make a new call, other intercoms waiting for the calling.

### **Q4: Unable to hear anyone because of too much noise and hiss.**

- A4:** 1) Move towards other members (make the distance of the intercoms within 150ft).  
2) Move to an open and flat area, restart the intercom, and try again.  
3) Stay away from equipment that will cause interference.

**\*If you have any question about the intercom, please contact us without hesitant!**

## Customer Guarantee

We provide a **30-day money-back** guarantee for any reason (free shipping) and **1-year warranty** (transportation prepaid) to the original purchaser against manufacturing defects in materials and workmanship.

**Note:** This Warranty is void if the damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair or alteration, improper or abnormal usage, or faulty installation, or any other reason.

## Customer Service

Contact our friendly support team for quick solutions.

**Friendly reminder:** When contacting us for help, be sure to have your product handy for troubleshooting!

### Contact us

\* Order list--Choose the order--Get help with order.

\* Contact our email to get service..

**Email:** Chunheeus@126.com



ChunHee Store