

anko

Pop-Up Beach Shelter Instruction Manual

Keycode: 43-564-361

FOLD BACK INSTRUCTIONS:



1. Stand the shelter upside down.



2. Then grasp the left and right sides of the shelter.



3. Then set the shelter upright with the entrance facing upward.



4. Grasp the middle part of the two top rings with your left hand, then use both hands to buckle and press the shelter inward at the same time to form a '8' shape.



5. Place the ring with the white strap on top. Keep one hand pressing down on the middle, and use the other hand to push the bottom ring toward the center. Finally, fold the "8"-shaped ring into a single ring.



6. Clamp the shelter with your legs to prevent it from springing open.

7. Then tighten it with the strap.

8. Put the shelter into the storage bag.

WARNINGS: THE AMOUNT OF SUN PROTECTION RECEIVED WILL VARY DEPENDING ON THE CORRECT POSITIONING OF THE SHADE. PLEASE NOTE THE SUGGESTED POSITIONING. REFLECTIVE RAYS CAN ALSO CAUSE SUN BURN. SUNSCREEN SHOULD BE WORN AT ALL TIMES. ALWAYS SECURE THE BASE OF THE SHELTER WHEN USING. DO NOT USE THE CABANA IN WINDY CONDITIONS. HANDLE WITH CARE WHEN OPENING AND CLOSING. DO NOT USE THE SHELTER ON THE STONE TO PREVENT IT FROM BEING CUT. KEEP AWAY FROM OPEN FLAMES OR HEAT SOURCES. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.

CAUTION: THE TENSION CREATED BY THE MECHANISM CAN CAUSE THIS SHELTER TO POP OPEN QUICKLY. ENSURE THE AREA IS CLEAR PRIOR TO SET UP.

CARE INSTRUCTITONS: WIPE CLEAN WITH A DAMP CLOTH. DO NOT USE ABRASIVE MATERIALS OR SOLVENTS. ENSURE ITEM IS CLEAN AND 100% DRY BEFORE STORING. STORE IN A DRY PLACE.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567