



MOTOTRBO™ R7

PORTABLE TWO-WAY RADIOS

QUICK REFERENCE GUIDE

en-US



MN007839A01-AC

DECEMBER 2023

© 2023 Motorola Solutions, Inc. All rights reserved.

Your Quick Reference Guide

This Quick Reference Guide covers the basic operation of the radio. Check with your dealer or system administrator because your radio may have been customized for your specific needs.

Your radio will need to be provisioned before use. This is typically done by your dealer or system administrator and customized for your specific needs. For more information, refer to the following link: https://www.motorolasolutions.com/en_xa/products.html.

<i>R7 Series User Guide</i>	MN007848A01
-----------------------------	-------------

<i>R7 Provisioning Guide</i>	MN007868A01
------------------------------	-------------

Important Safety Information

RF Energy Exposure and Product Safety Guide for Portable Two-Way Radios

Product Safety and RF Exposure Compliance

 **CAUTION:** Before using this product, read the operating instructions for safe usage contained in the Product Safety and RF Exposure booklet enclosed with your radio.

ATTENTION!

This radio is restricted to Occupational use only. Before using the radio, read the RF Energy Exposure and Product Safety Guide for Portable Two-Way Radios which contains important operating instructions for safe usage and RF energy awareness and control for Compliance with applicable standards and Regulations.


Computer Software Copyrights

The Motorola Solutions products described in this manual may include copyrighted Motorola Solutions computer programs stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola Solutions certain exclusive rights for copyrighted computer programs including, but not limited to,


the exclusive right to copy or reproduce in any form the copyrighted computer program.

Accordingly, any copyrighted Motorola Solutions computer programs contained in the Motorola Solutions products described in this manual may not be copied, reproduced, modified, reverse-engineered, or distributed in any manner without the express written permission of Motorola Solutions. Furthermore, the purchase of Motorola Solutions products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Motorola Solutions, except for the normal non-exclusive license to use that arises by operation of law in the sale of a product.

Radio Controls



1. Antenna
2. LED Indicator
3. Front Microphone
4. 3-Dot Programmable Feature button
5. Push-to-Talk (PTT) button
6. 1-Dot Programmable Feature button
7. 2-Dot Programmable Feature button
8. Emergency button
9. Display¹
10. Keypad¹
11. Speaker
12. On/Off/Volume knob
13. Channel Selector knob
14. Rear Microphone
15. Belt Clip Slot
16. Charging Contacts
17. Charging Rail
18. Device Labeling Area
19. Accessory Connector
20. Lanyard Hole



Attaching the Battery



NOTE:

For optimal performance, charge a new battery 14 to 16 hours before initial use.

1. Align the battery with the rails on the back of the radio.
2. Press the battery firmly, and slide upwards until the latch snaps into place.
3. Slide battery latch into lock position.

¹ Not for Non-Keypad models.

Attaching the Antenna

1. Turn off the radio.
2. Set the antenna in the receptacle and turn clockwise.

Turning the Radio On and Off

Rotate the **On/Off/Volume** knob clockwise or counterclockwise until a click sounds.

Adjusting the Volume

Rotate the **On/Off/Volume** knob clockwise or counterclockwise.

LED Indicators

Blinking Red

Radio has failed the self-test upon powering up, has moved out of range if Auto-Range Transponder System is configured, has Mute mode enabled, is receiving an emergency transmission, is transmitting in low battery state, or is indicating a battery mismatch.

Solid Green

Radio is powering up, transmitting, or sending a Call Alert or an emergency transmission.

Blinking Green

Radio is receiving a call or data, detecting activity over the air, or retrieving Over-the-Air Programming transmissions.

Double Blinking Green

Radio is receiving a privacy-enabled call or data.

Solid Yellow

Radio is monitoring a conventional channel or in Bluetooth Discoverable Mode.

Blinking Yellow

Radio is scanning for activity, has Flexible Receive List enabled, has yet to respond to a Call Alert, or all Capacity Plus-Multi-Site channels are busy.

Double Blinking Yellow

Radio has Auto Roaming enabled, has yet to respond to a Group Call Alert, is actively searching for a new site, is not connected to the repeater while in Capacity Plus, is locked, or all Capacity Plus channels are busy.

Lightbar Color Indicators

The following color indicators appear on the home screen at the left side of the radio display.

Light Blue	Radio is available for call.
Yellow	Radio is receiving call.
Red	Radio is transmitting call.
Grey	Radio is unprogrammed or not connected.

Display Icons

The following icons appear on the status bar at the top of the radio display. The icons are arranged left most in order of appearance or usage, and are channel-specific.

	Emergency
	Scan
	Notification
	Tone Disabled
	Battery
	Secure

	Unsecure
	Bluetooth Connected
	Auto Roaming
	RSSI
	Talkaround
	Wi-Fi
	Power Level
	Tx Inhibit
	Mute

NOTES

www.motorolasolutions.com/mototrbo

MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners. © 2012 and 2023 Motorola Solutions, Inc. All rights reserved.

