

TMKB M1 Driver Software User Manual

Complete Guide: Master all customization features of your TMKB M1 mouse



Table of Contents

1. Switch Lighting Effects	4. Adjust DPI Settings
2. Remap Keys	5. Change Performance Parameters
3. Record Macros	

1. How to Switch Lighting Effects

Note: The default lighting effect is "Streaming Colors".


Click the mouse to switch between other lighting effects. Available options include 13 effects plus "Lights Off":



2. How to Remap Keys


Click to select Key1/Key2/Key3/Key4/Key5/Key6 on the right panel.

Configure functions including: Key Mapping, Key Combinations, Media Shortcuts, Key Disable, and Macro Recording.




3. How to Record Macros


Access Macro Manager: Click the Macro Manager tab at the top to enter the macro recording interface.




Create Macro Folder: Click the red "+" icon next to Macro Category List to create a macro folder (category).




Create Macro Command: Click the grey "+" icon next to Macro Manager to create a new macro command file.




Start Recording: Select the newly created macro file. Click the white play (▶) button next to Macro Name in the bottom-left area to start recording your macro actions.



Stop Recording: Click the red pause (⏸) button next to Macro Name in the bottom-left area to finish recording.




Assign Macro to Key: Click the Configurations tab at the top to return to the main interface. Your recorded macro will appear in the bottom-left area. Select the macro file. Then, click the target key (Key1-Key6) in the top-right visual area. Finally, click the Set button in the bottom-left to assign the macro to the selected key.



4. How to Adjust DPI & Set Default DPI Levels

Select the DPI option on the main interface.

Adjust DPI levels by dragging the DPI value sliders.



Tip: You can set up to 7 DPI levels and switch between them using shortcuts.

5. How to Change Key Performance Parameters

Select the Advanced option on the main interface.

Configure settings for: Mouse Polling Rate, Sleep Time, Fire Key, and other functions.

