
Features F06 **Product Instructions** Removable Assistationapy Cover Removable Protective Net Temperature Display O Night Light Mode Adjustment Turn On Ov Of / Speed Gee Adjustment / Cycle Mode O USB Charging Port. Suspended Base O Night Light O Charging Indicator Exterior Size Steps For Usage 131mm + Open the box and take out the circulating fan from the box. Connect the circulating fan to a USB charger for charging. The red indicator light is always on when charging, and the indicator light turns green when fully charged. Manually adjust the flip circulation fan to a proper angle (Adjustable to 90"). Basic Configuration Operating Description -(E) Power Consumption The touch button operation is as follows: Long prime (Figure 1) with your finger position to turn until the fan-mode, click again to adjust the fan 1/2/3/4 geer joksk and truch finguency infernal 0.5 seconds), double click to turn printf the fan-rudation cycle mode (5 seconds) alter power us The seat-time temperature is displayed by default without using the touch tratter). Betery Spechostore Charging Time

(3) Decibel Velue or none Long press (Figure 2) linger position to turn ontoff right light mode.
 zlick again (Figure 2) finger position to situatingly beginness (olick and touch frequency interval 0.3 sectorist), disuble click (Figure 2) finger position to advise light mode (5.15.2) (ASLA), three are four agitting modes: stool whiteleast whiteleast whiteleasting light.

Protective Net Removal







- Turn the fan to 90° and unscrew the screws on the back of (Figure 1).
- . Then turn the protective net (Figure 2) dockwise to a buckle
- Finally, the protective net can be disasteribled and cleaned

Aromatherapy Cover Disassemble





Ridate the anametherapy cover counterdackwise is remove the avorablerapy cover (the product does not contain aromatherapy)

Warranty Card -----

Jiantarie	Purchase Date
Contact Number	Installation Address
Product Name	_
Dealer (Signature):	

This product has been strictly inspected before leaving the factory to ensure that its quality meets versions standards.

Maintenance Records

Asset Color	Mokramous Propos	Martin aca-	Reporter's Riginature

Note: (5) Please weep this card properly, and contact the after-sales service center with the warranty roard and purchase invoke when repairs are meded.

- repairs this medical.

 (2) The promptory guarantees: I year for the FOS circulating fan bursthesed by the sees, and the repair content includes; fan, control parels, etc. (sessed for the feet consumities, normal fan channing and residence. In the later period).

 (3) The company's warranty card is only for use in China (excluding rhang Kong, Macoo, and Taleson);

 (4) The warranty card shall not be altered or furger.









(f) Treing

(B) Tentative

(2) Crossey Fee B) Tue Of Omalety Fee

- (c) Marques Mode
- (E) Resetting Light
- (0) Cold Lagre Mode
- (N) Warri And Cold Lagra Made
- (a) Marri Light Mode

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- —Reorient or relocate the receiving antenna.
 —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician