









285x210mm



USER'S MANUAL

Christmas Tree

CM23664/CM23719/CM23720/CM23721/CM23722/CM23723  
/CM23675/CM23727/CM23676/CM23677/CM23728

<div><div>A</div><div>x 1</div></div>	<div><div>B</div><div>x 1</div></div>	<div><div>C</div><div>x 1</div></div>
<div><div>D</div><div>x 1</div></div>	<div><div>1</div><div>X 3</div></div>	
<div><div>B2</div><div>x 1</div></div>	B2 only for 2.7 M(9ft) tree	
1.5M (5ft) tree only have A, C & D.		
<div><div>2</div></div> <div>WARNING:There are plastic caps on the end of each pole that are useless,please make sure to remove them before assembling. If the caps were broken or missing, please don't worry.</div>		

