
**USER GUIDE** 






# 5000 LUMENS FULL HD PROJECTOR (F800)


KAF800PRRA


# **SAFETY & WARNINGS**

- Do not open the case as this may pose a risk of electric shock.
- Do not attempt to repair this product yourself. If the product or its power supply
  experiences any malfunction or damage, stop using it immediately and contact
  Kogan.com to arrange a repair.


# **OVERVIEW**









### **Ports**





# **OPERATION**


## **Input Source Selection**



Press the input button to select signal source.



# **USB** Input




The projector can read files from a connected USB drive.


#### **HDMI CEC**

CEC (Consumer Electronics Control) allows users to control multiple HD devices that support CEC with one remote control, eliminating the need to use multiple remote controls to control electronic devices such as televisions, TV boxes and portable HD devices.

1. Connect device(s) which support CEC to the projector by HDMI.




2. Choose SETTING > OPTION > HDMI CEC > Device List




3. Search for and select the device(s)



# Image Adjustment - Keystone



# Image Adjustment – Focus



## **Projection Size and Distance**

Optimum projection distance: 3m

Distance	Screen size
1.5m	35"
1.75m	50"
2.4m	72"
3.3m	100"
3.9m	120"
5.5m	180"
7m	300"


# **Ceiling Mount Installation**

This projector is compatible with most universal wall mounts (sold separately)

- 1. Remove the four rubber feet
- 2. Enter MENU > PICTURE > Projection Mode and select the ceiling mounted option to invert the picture.



# IN THE BOX



#### **Need more information?**

We hope that this user guide has given you the assistance needed for a simple set-up. For the most up-to-date guide for your product, as well as any additional assistance you may require, head online to **help.kogan.com** 

