



Connecting your RadioLink T8S(BT) T8FB(BT) to your Apple or Android device



1. From the App Store, upload the FREE RadioLink_Blue App to your Apple or Android smartphone / device.



2. Ensure you have Bluetooth switched ON in your phone settings.
3. Open the RadioLink_Blue App.
4. Turn ON the T8S(BT) T8FB(BT) transmitter.
5. Press the 'Connect' button in the top left corner of the App's home screen.
6. Select 'RadioLink RSSI' from the list of Bluetooth devices.



7. With this the transmitter will start to beep, at which point you should press one of the trim buttons to confirm connection. The transmitter will then stop beeping.
8. You can confirm connection by moving the sticks on the transmitter and noting representative movements on the app's servo output graph.

Now that you have the app and transmitter connected you can adjust parameters and save model memories to your smartphone ready to be recalled to your T8S(BT) T8FB(BT) at the field, lake or track. It's that easy.