













Dell Pro 27 Plus 4K USB-C Hub-skärm
P2725QE





























1







2




3







Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/P2725QE