

OUTDOOR PIZZA OVEN INSTRUCTION


This manual is applicable to the following models:

MODEL:

PHO_167UEV5K

PHO_167U56PH

PHO_167ULIZ6



Please be careful of any sharp edges & corners,keep away from children.

This is the original instruction, please read all manual instructions carefully before operating. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if here are any technology or software updates on our product.



Warning-To reduce the risk of injury, user must read instructions manual carefully.

Please contact Email address: **After_sale@sericve.com**

If you have any questions.

Our team will reply within 24 hours and will do our best to resolve your problem for you.

Warnings

- This pizza oven is FOR OUTDOOR USE only and shall not be used in a building, garage, under overhangs or any other enclosed area.
- DO NOT leave a lit pizza oven unattended. Keep children and pets away from the pizza oven at all times.

PROP 65 WARNING

This product can expose you to chemicals including Chromium(hexavalent compounds), which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information visit www.P65Warnings.ca.gov.

IMPORTANT SAFETY

Please read this manual carefully and before installing or using your pizza oven to ensure This manual should be retained for your information.

LOCATION OF PIZZA OVEN

Remember that your pizza oven is an outdoor appliance. Ensure your pizza oven is positioned safely away garages or any other enclosed area. This outdoor cooking appliance is not approved to be installed in or on any recreational pizza ovens are intended for single-family/residential use only.

Minimum clearance from sides and back of unit to combustible construction, 36 inches from back and sides.

When determining a suitable location, take into account concerns such as exposure to wind, proximity to Proper location and use is also essential to ensure safe and continued trouble-free operation. Any non-approved alterations made to the pizza oven will void its warranty.

INSTALLATION WARNINGS

Please read all installation, operating, and maintenance instructions thoroughly before installing or servicing this equipment.

Warnings

This pizza oven is for outdoor use only. The manufacturer cannot be held responsible for damage or injury caused by improper use of this appliance.

FUEL CONCERNS & EXPLOSION HAZARDS

Do not store or use gasoline or other flammable vapors and liquids (that are not connected for use) in the vicinity of this or any other appliance. Keep the area clear and free from combustible materials, gasoline, and other flammable vapors and liquids, Failure to do so can result in death, explosion or fire.

Keep an ABC fire extinguisher accessible at all times, and never attempt to extinguish a grease fire with water or other liquids. Do not attempt to heat unopened containers on the pizza oven. Pressure may build up and cause the container to explode. Never use charcoal or any other solid fuel in the pizza oven.

PROPER USE PIZZA OVEN

This pizza oven is NOT intended for commercial use. Do not operate the pizza


oven in a building,garage, or any other enclosed areas. This could result in carbon monoxide buildup,which may cause injury or death, pizza ovens are not designed or intended for installtion near a window or vent that feeds into the house.

Consult the AHJ(Authority Having Jurisdiction) or a contractor in your area if you have any uncertainty regarding local codes.

GENERAL WARNING


- Do not touch hot surfaces.
- Use insulated oven mitts when operating the pizza oven.
- Never lean over the cooking surface when lighting or operating the pizza oven.
- Close supervision is necessary when this or any pizza oven is used near children.
- Keep children away from the grill during operation and until it has cooled off.
- Never operate this pizza oven while under the influence of alcohol or drugs.
- Do not store anything in the pizza oven. Make sure food is not forgotten in the pizza oven body;forgotten items could melt or catch fire when the pizza oven is turned on.
- Never use the pizza oven in WINDY conditions. If located in a consistently windy area (oceanfront, mountaintop, etc.), a wind break will be required. Winds blowing into the back can result in poor performance and/or cause the control panel and knobs to get dangerously hot.
- To prevent injuries, do not use accessories that are not recommended by the manufacturer.
- The use of accessories, regulators, or components not recommended by the appliance manufacturer may cause injuries and will void warranty.

No.	Part name	Qty	No.	Part name	Qty
1	Body	1	8	Pellet box	2
2	Chimney	3	9	Pellet box grate	2
3	Spit	1	10	Pellet spoon	2
4	Door	2	11	Pellet inlet handle	2
5	Pellet inlet	2	12	Rotating handle	1
6	Handle	1	13	Grill body	1
7	Pizza stone	1	15	Slag tray	1



No.	Part name	Qty	No.	Part name	Qty
1	Body	1	8	Pellet box	2
2	Chimney	3	9	Pellet box grate	2
3	Chimney cap	1	10	Pizza spatula	2
4	Door	2	11	Pellet inlet handle	2
5	Pellet inlet	2	12	Ash tray	1
6	Pizza cutter	1	13	Handle	1
7	Pizza stone	1			

Spare part



A.M5*12MM X 9

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts

with package contents list on previous page and hardware contents below. If any part


is missing or damaged, do not attempt to assemble the product. Contact customer service for replacement parts.

CAUTION:

Some parts may contain sharp edges. Wear protective gloves if necessary. Read and follow all safety statements, warnings, assembly instructions and use and care instructions before attempting to assemble and use.


ASSEMBLY INSTRUCTIONS

1. Unfold legs




2. Install the handle screw

A M5*12MM 4 PCS




3. Install chimney screws

A M5*12MM 3 PCS




4. Install the chimney




5. Install the pellet inlet parts

A M5*12MM 2 PCS



6. Installing ash collecting tray




7. Install the pellet box


7.1 Put the particle box grille into the particle box.

7.2 Put the granules into the granule box.

7.3 After ignition, put the particle box into the pizza oven body through the particle inlet handle.




8. Install the pizza stone.



9. Install the door

Screw the handle into the door and place the door on the body opening



Replenishing the pellet

- During cooking, keep the pellet in hopper assembly at more than half the capacity of the hopper assembly.
- To replenish the pellet during use, use the handle to open the hopper assembly lid, then use the hopper shovel to take some pellets and pour them into the hopper assembly. Place the hopper assembly lid back on the hopper assembly with the handle.
- Make sure oven gloves or mitts are used.

Remark:

- when you cook around 20mins later, have better to add some more pellet in the carbon box.
- Take out a little of the carbon box.
- Please dispose all plastic bags carefully and keep it away from children..Always use heat resistant gloves when handling the product..Use flame gun to make fast burn again.
- Take a few moments to familiarize yourself with the contents & before starting check all holes are clear of any paint residue.

Water:

- Water can damage the inside of your oven. You must ensure that no water enters the oven chamber, either through the oven door opening, or through the chimney.
- Always place the provided metal door in the oven opening when not in use to stop water from entering through the opening into the oven chamber.. Do not install the oven at a backward-leaning angle, where water could enter the oven and pool, causing damage..Do not ice or wet-mop the oven floor.
- Water is not required to clean the cooking floor, The oven operates at very high temperatures.The high heat act as an automatic "self-cleaning" mode, burning off all spilled or stuck-on foods. If stuck-on food is a problem during cooking, you can remove it with a brass oven brush As a preventative measure, nondough based foods should always be placed on appropriate cookware before being placed in the oven.

Maintenance and Cleaning Instructions:

CAUTION: All cleaning and maintenance should be carried out when the pizza oven is cool.

OUTSIDE SURFACE

Use mild detergent or baking soda and hot water solution. Non-abrasive scouring powder can be used on stubborn stains, then rinse with water. If the inside surface of the pizza oven lid has the appearance of peeling paint, baked on grease build-up has turned to carbon and is flaking off. Clean thoroughly with strong hot soapy water solution. Rinse with water and allow to completely dry. **NEVER USE OVEN CLEANER.**

INTERIOR OF BARBECUE BOTTOM

Remove residue using brush, scraper and/or cleaning pad then wash with a soapy water solution.

Rinse with water and allow to dry.

COOKING GRID


Use a mild soapy water solution. Non-abrasive scouring power can be used on stubborn stains then rinse with water.

INTERIOR OF BARBECUE BOTTOM

Remove residue using brush, scraper and/or cleaning pad then wash with a soapy water solution Rinse with water and allow to dry. it should be clean the carbon deposition after use.

WARNING!

Danger of sufocation! The oven is intended for outdoor use only. it must not be used in building, garages or other closed areas. Toxic fumes may form, which can lead to suffocation.



IMPORTANT SAFETY INSTRUCTIONS



WARNING

Hazardous fire or explosion may result if instructions are ignored

It is the consumer's responsibility to see that the barbecue is properly assembled, installed, and taken care of. Failure to follow instructions in this manual could result in bodily injury and/or property damage.

- Read the instructions before using the pizza oven.
- Retain this use & care guide for future reference.
- Use outdoors only.
- Warning accessible parts may be very hot. Keep young children away.
- Do not move the pizza oven during use.
- Do not modify the pizza oven.
- This pizza oven must be kept away from flammable materials during use. The pellet will be very hot so take suitable precautions.
- Do not leave the handle on the pizza oven.
- Never touch metal parts that may be hot.
- Do not cook before the fuel has a coating of ash.

General Safety Guidelines

Must be read in full prior to use

Please read the general safety guidelines fully before assembling, installing and using/servicing your pizza oven. Failure to comply with all the provisions of the present legal disclaimer could result in property damage, serious bodily injury or even death.

1. Pizza oven is designed for outdoor use only. The pizza oven must always be placed outdoors, away from structures and never inside a building or a garage or in proximity to any enclosed area. Place your pizza oven on a sturdy, level, stable and non-flammable surface and keep it clear and free from flammable or combustible materials, gasoline and other flammable vapors and liquids.

2. Be aware of any local laws or regulations that may specify a required distance between outdoor cookers and any structures, or that may limit outdoor flame of any type during drought or hazard periods.
3. Do not install or use your pizza oven in or on boats or recreational vehicles.
4. Do not use your pizza oven in high winds.
5. Your pizza oven is not intended to, and should never be used as a heater.
6. Toxic fumes can accumulate and may cause asphyxiation.
7. Flames can blow outside of the metal enclosure:
 - a. at the back where the fire is;
 - b. from the top of the hatch when the lid is opened;
 - c. from the front of the oven when you open the door; or
 - d. from the top of the chimney.
8. Please keep away from the pizza oven's openings and warn others around you.
9. Improper installation, adjustment, alteration, service or maintenance of your pizza oven may cause injury or property damage. Therefore, do not use your pizza oven unless it is completely assembled and all parts are securely fastened and tightened.
10. When using the pellet burner:

The length of pellets used can greatly affect the temperature of your pizza oven. The recommended pellet length should be no longer than 1.25" (3cm). Longer pellets have a slower feed rate which can cause your pizza oven to burn colder. When changing or refilling pellets be aware of the average length and adjust your pizza oven setting accordingly. Only use pellets intended for use in cooking.
11. When using the charcoal/wood burner: Add the kindling gradually to reach an optimum temperature. Adding too much kindling will enlarge the fire, risking damage to you or your pizza oven.
12. When using your pizza oven, there is a risk for your hands to be burned. Protective heat resistant gloves should be worn at all times to avoid burns and you should never set hot items on or near combustible surfaces. DO NOT touch any metal parts when your pizza oven is operating. Only touch the wooden handles to open the door and lift the fuel hatch.
13. Never leave your pizza oven unattended. Do not leave your pizza oven unattended with the lid open while lit. Be aware of hazards (dry leaves, decking and other combustible materials) that may be in proximity to the

pizza oven while it is in use as they may present a fire hazard if any sparks are allowed to come into contact.

14. Keep all electrical cords away from your pizza oven. Pizza oven (when being used) ranges from 100°F (50 °C) to 1200°F (650°C).

15. Pizza oven is safe and hazard free when used as intended and according to safety guidelines and will provide years of trouble-free use and enjoyment. It is the user's responsibility to maintain safe operation of the pizza oven and to exercise reasonable standards of care at all times. 16. Whilst every effort has been made in manufacture of your barbecue to remove any sharp edge, you should handle all components with care to avoid accidental injury.



WARNING

NOTE FOR CONSUMER: Retain for future Reference

This pizza oven is designed for use outdoors, away from any flammable materials. It is important that there are no overhead obstructions and that there is a minimum distance of 122cm (4 ft.) from the side or rear of the appliance. It is important that the ventilation openings of the appliance are not obstructed. The barbecue must be used on a level, stable surface. The appliance should be protected from direct draughts and shall be positioned or protected against direct penetration by any trickling water (e.g. rain).

IMPORTANT REMINDER

Please make sure the door is closed during baking except when putting or fetching food, otherwise fire may come out from the back of oven and it's hard to keep the baking temperature inside oven.