



1 |




2 |




3 |




4 |




5 |




6 |






7 |



8 |




Do not position light sensor below edge of cover (IR only).




**FLEXIDOME IP 4000i | 5000i (IR) outdoor |
FLEXIDOME IP starlight 5000i (IR)
outdoor**


NDE-4502-A | NDE-4502-AL | NDE-5503-A |
NDE-5503-AL | NDE-5502-A | NDE-5502-AL |
NDE-4512-A | NDE-4512-AL




en Quick installation guide



**Project Assistant App + Configuration
Manager + Video Security Client**
Windows | iOS | android



<https://downloadstore.boschsecurity.com/>



Bosch Security Systems B.V.

Torenallee 49
5617 BA Eindhoven
Netherlands

www.boschsecurity.com

© Bosch Security Systems B.V., 2022

Building solutions for a better life.

2022.02 | V09 | F.01U.329.066 | 202202181254