






Installation Guide


ECL Comfort 210 / 296 / 310, A267 (code no. 087H3816)




A267.1 (ex. a):




A267.1 (ex. b):



A267.1 (ex. c):




A267.1 (ex. d):




Danfoss
87H2150,11

A267.1 (ex. e):




Danfoss
87H2151,11

A267.1, ex. f:



ECL Comfort 210 / 296 / 310:
230 V a.c.

R	4 (2) A / 230 V a.c.
R	
Tr	0,2 A / 230 V a.c.




230 V a.c.

A267.1 ex. a, A267.1 ex. d: P2

A267.1 ex. b, A267.1 ex. f: P2

A267.1 ex. c, A267.1 ex. e: P2



ECL Comfort 310:

24 V a.c.


R	4 (2) A / 24 V a.c.
Tr	1 A / 24 V a.c.

24 V a.c.

A267.1 ex. a, A267.1 ex. d: P2





A267.1 ex. b, A267.1 ex. f: P2

A267.1 ex. c, A267.1 ex. e: P2





230 V a.c. / 24 V a.c. safety thermostat

1-step closing





230 V a.c. / 24 V a.c. safety thermostat

2-step closing




A267 (ECL 210)


Pt 1000 (1000 Ω / 0 °C)



ECA 30 / 31




Danfoss
87H2051,12




Danfoss
87H1254,13

Master / slave




Danfoss
87H2052.11


Modbus




M-bus




M-bus



Pt 1000 (IEC 751B, 1000 Ω / 0 °C)




Heat curves




ECA 30


1




2




3




4




5




6



7




8




Installation Guide, ECL Comfort 210 / 296 / 310, A267


Danfoss
87H1021.11




Danfoss
87H1017.11



Danfoss
87H1073.11



Danfoss
87H1074.11



? **ECL Comfort 210 / 296 / 310, A267: www.heating.danfoss.com**

? **<https://www.youtube.com/user/DanfossHeating>
-> Playlists -> How-to Videos -> District Energy installation videos**



Danfoss A/S

Heating Segment • danfoss.com • +45 7488 2222 • E-Mail: heating@danfoss.com

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequent changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and all Danfoss logotypes are trademarks of Danfoss A/S. All rights reserved.