

HARMAN PRESSURE SWITCH HOSE 1-00-5113574

INSTALL INSTRUCTIONS

How to install

1. Unplug the stove.
2. Open or remove any rear access panels from the stove.
3. Locate the switch in the rear of the stove. There is a white wire coming from the controller to one side of the switch and there are two light blue wires connected at the terminal on the other side of the switch.
 - These light blue wires run to the igniter and to the feed motor.
4. Disconnect the air tube.
5. replace the old air tube with the new air tube.
6. Reattach the access panels back onto the stove.