


HOT DOG STEAMER

User Manual



Manufacturer: Guangzhou Naibao Mechanical and Electrical Equipment Co. , Ltd.

Company address: No.1, Long Xin Street, Long Kou Village, Hua Shan Town, Huadu

District, Guangzhou City, Guangdong province

INSTRUCTION MANUAL

CONTENTS

1.INTRODUCTION.

2.SPECIFICATIONS&FEATURESSAFETY.

3.ELECTRICAL SCHEMATIC.

4.BEFORE USE.

5.TRANSPORTATION AND MAINTENANCE.

6.OPERATION.

7.PARTS & ASSEMBLY.

8.DECOMPOSITION TABLE.

9.ASSEMBLY CUE.

1.INTRODUCTION

This machine was used to warm up hot dog and bun by steaming.Hot dog steamer makes you easy to prepare delicious hot dogs .This equipment was easy

clean and operate. It will be ideal for use in rental shops ,convenience stores,vending carts food restaurants,snack bars or many others。

2.SPECIFICATIONS & FEATURES

Model	voltage V	Frequency Hz	Power KW	Outline dimension mm
NB-RGG-001	110	60	0.5	342×382×510

3.SAFETY

1. Do not operate the appliance with a damaged cord or plug.or if the machine is malfunctioning or damaged. Send the unit to the nearest authorized service center for examination and repair.
2. This equipment use cable model YZW.specifications $3 \times 1\text{mm}^2$,Yellow green ground wire.
3. Voltage of this machine was written on rating plate at side of machine.
4. Place machine on a flat and stable surface,connect with DX47-63,C16 Leakage air Switch and three-prong plug
5. This appliance must be grounded while in use to protect the operator from electrical shock
6. Unplug main power cord from outlet from outlet while not in use and before cleaning.Allow to cool,clean and cover the unit and store in a dry and safe place if Not being used for a long time.
7. To avoid any risk of electrical shock ,do not immerse cord,plug or machine into water or other liquid.


8. This appliance must be grounded to make sure safe.

Note:Water level protection will shut down machine power, when machine lack water. You need turn off machine and refill water first, than you can turn on machine.

CAUTION:NEVER immerse in water or near water

HOT on machine surface,please do not touch,In case of hurt.

4.ELECTRICAL SCHEMATIC:



5.BEFORE USE

1. This appliance connect with Leakage DZ121/1N, Leakage current15mA.
2. Machine should store in a dry and safe place,40°C below.

3. Place machine on a flat and stable surface, tilt less than 3°
4. Water level must never more than $2/3$ height of water box and never less than $1/3$.

6.TRANSPORTATION AND MAINTENANCE:

Glass inside machine,handle with care during transportation,in case,DONOT use outdoors.Store in a dry and safe place after use, please do not upside down machine.Do not install pool or water.






7.OPERATION:

1. Close drain value.
2. Please unplug power cord,When you add water .Turn off drain valve,remove glass door and steam plate. Pour clean water in water in water box,water level must never more than $2/3$ height of water box and never less than $1/3$.
3. Install steam plate and glass door back.
4. Put hog dog on steam plate and bun on bread plate, Close glass door.
5. Plug power cord,Turn on power switch ,and turn on temperature controller at $50-60^{\circ}\text{C}$.
6. 10 minutes later ,warm and fresh hot dog ready for your service.

Note:Water level protection will shut down heat power, Please unplug machine and refill water.

7. Machine need be cleaned everyday.
8. Please check water level never less than $1/3$,before use
9. Please drop all water,if the equipment not use for a long time In case,water go to bad.

8.Decomposition table:

NO	PART	QTY	NO	PART	QTY
1		1	2		2
			3		1
			4		2
			5		2

9.Assembly cue:

