




READY FOR YOUR NEXT JOURNEY

EN - INSTRUCTIONS FOR CHANGING THE CODE:

The original combination is 0-0-0. To set your own combination, please follow below easy steps:

1. Press the buckle and pull up the strap to open the lock
2. Press the setting button inside of the buckle and then set your own combination
3. Release the setting button and the setting is completed

To set a new combination, please repeat step 1 to 3 above, please remember your new combination.





READY FOR YOUR NEXT JOURNEY

NL - INSTRUCTIES VOOR HET WIJZIGEN VAN DE CODE:

De originele combinatie is 0-0-0. Om je eigen combinatie in te stellen, volg dan de onderstaande eenvoudige stappen:

1. Druk op de gesp en trek de riem omhoog om het slot te openen.
2. Druk op de instelknop in de gesp en stel dan je eigen combinatie in.
3. Laat de instelknop los en de instelling is voltooid

Om een nieuwe combinatie in te stellen herhaal je stap 1 tot 3 hierboven, onthoud uw nieuwe combinatie.

