



JX116B

BLUETOOTH TWS EARPHONES



USER MANUAL

Product Description



- 1: Multi-function touch button
- 2: Earbud indicator/talk microphone
- 3: ENC Noise cancellation microphone
- 4: Earbuds charging contacts
- 5: Indicator light
- 6: Type-C USB charging port

Power On/Off

Auto power on: Open the charging box case and power it on automatically .
Auto power off: The earphones will shut off when placed back into the charging case and the lid is closed. If no device is connected within 5 minutes, the earphones will automatically shut off.

Bluetooth Pairing

- 1 Open the charging box case and power it on automatically .
- 2 After turning on, put the left and right earphones close to each other. After the team is successful, the indicator light: the main earphone flashes red and white lights alternately, and the auxiliary earphone flashes white light once 5 seconds .
- 3 Open the phone's Bluetooth connection interface, search for "JX116B ", click pair then the connection is successful and accompanied by a tone.

Music

- ▶ Music pause/play: During playback, Double-click the multi-function touch button.
- ▶ Volume down: One click the right ear multi-function touch button.

- ▶ Add volume: One click the left ear multi-function touch button.
- ▶ Previous song: Long press 2s the left ear multi-function touch button.
- ▶ Next song: Long press 2s the right ear multi-function touch button.

Wake Up Voice Assistant Function (requires mobile phone support)

- ▶ After successfully connecting to the mobile phone, except during calls, tapping the multifunctional touch button on the right side of the headphones four times will the voice assistant function (SIRI).

Game Mode

- ▶ Double-click the multifunctional touch button on the headphones to turn on/off the game mode.

ANC model switch

- ▶ ANC switching order: normal mode - transparency mode - ANC mode Note
- ▶ ANC mode: it will switch back to normal mode each time it is back in the charging case and taken out again, and it will automatically switch to normal mode when entering the call state.

Call

- ▶ Answer: When a call comes in, double-click the multi-function touch key.
- ▶ Reject : When there is an incoming call, press and hold the multifunctional touch key for 2 seconds.
- ▶ Hang up: During a call, double-click the multi-function touch key.

Headset Restore Factory Settings

- ▶ When both earphones are turn on at the same time and not connect to mobile phone, click any one of the earphones 5 times. When the operation is successful, the left and right earphone lights will flash white quickly 3 times at the same time, then earphone light will turn off and the main earphoner and white lights will flash alternately to enter the waiting state

Charging

- 1 The charging case is charged by the charging cable when charging case is charging, the red light flash and after the full charging, the indicator light should be on.
- 2 The earbud is placed in the charging case, automatically charged, and the earbud indicator is off after being fully charged.

Earbuds charging	Red light is on
Earbuds is fully charged	Red light is off
Charging case is charging	Red light flash
Charging compartment is fully charged	The light is always on

Specifications

- Model: JX116B
- Bluetooth version: 5.4
- Single earbud weight: 3.9g
- Earbud size: 33.5*21*23mm
- Earbud battery capacity: 3.7V/2*40mAh
- Earbud charging time: about 30 Minutes
- Play music time: about 7 hours (Medium volume)
- Support Agreement: A2DP, AVCTP, AVDTP, AVRCP, HFP
- Frequency: 2.4GHz-2.48GHz
- Bluetooth distance: 10M
- Power input: DC 5V/500mA
- Charging case battery capacity: 3.7V/400mAh
- Charging case to charge the earbud: 3 times
- Charging case size: 60*52.5*26.5 mm
- Charging case weight: 38g

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.