









1



Warning!
Read the directions for use before
operating the appliance


2

Positioning the docking station




3

Cutting height adjustment









4










Main switch location



5

Programming







For more information visit

VICTA.COM.AU

80095661



2373	A	SP	HN	QUICK START GUIDE, VICTA ROBOT MOWER RM100	27/05/20
ECN	ISS	DRN	CKD	DESCRIPTION	DATE