

porodo
LIFESTYLE
USER MANUAL



WATER & ICE
NANO MIST COOLING FAN
Model: PD-SACF

How to operate on the fan

1. The air cooler should be placed horizontally and not tilted. Open the filling tank and fill with tap water, not exceeding its maximum and minimum water level marks.
2. Turn on the cool "C" Fan function for 10-15 min and then turn off the fan "C" and "ICE" mode. It will take the next 10-15 min to fill up and produce nano mist. After that take the fan and dispose, and the air cooler has a life of four years.

After turning on the air cooler

1. Press on the cool "C" button. Turn on fogging. Air cooler display "C" icon is displayed. Press on the heat switch "H" button to turn off fogging, on the display "C" icon is off.
2. Long press on the heat "H" button turns off both the fan and the fog.

Remote Control



Product Parameter

Product name: PD-SACF

Size: 51x28

Net operating current: 1.5A (at 220V, 50Hz)

Working time: 10-15 min

Motor power: 10 W, 220 V~50 Hz, 0.05 A

Water tank: 500 ml

Water tank size: 150x100x100 mm

Product name: PD-SACF Type C

Power: 100 W, 220 V~50 Hz, 0.45 A

Water tank: 650 ml

Product weight: 8.5kg

Matters Needing Attention

1. Do not use for the heat. Please do not use it.
2. If case the battery capacity has passed the mark to charge again. Stop after 10 hours to charge.
3. Do not use the fan if the fan is broken or damaged.
4. Do not use the fan if the fan is broken or damaged.

Method of adding water to the air cooler

Add water with a drawer

As shown in the figure below, drag the yellow handle at the position of the tank drawer and pull it out to the appropriate position + lock handle.



Add water to the tank

As shown in the figure below, press the side position of the water tank to open the bristle, and at the same time use your hand to open the water tank down to remove and add water.



Add water/ice to the air cooler

After turning the tank you can add water/ice/ice cube.



Method of adding water to the air cooler

Method of adding water to the air cooler

Method of adding water to the air cooler

As shown in the figure below, drag the yellow handle at the position of the tank drawer and pull it out to the appropriate position + lock handle.



Add water to the tank

As shown in the figure below, press the side position of the water tank to open the bristle, and at the same time use your hand to open the water tank down to remove and add water.

