


# Do we deserve five stars?

Share your experience







#### Did we mess up?

Let our friendly support team make it right



obdlink.com/support



support@obdlink.com


## **Regulatory Compliance**

OBD Solutions, LLC hereby confirms that the product branded "OBDLink CX" complies with:


- REACH EC No 1907/2006
- RoHS Directive (2011/65/EU)
- Electromagnetic Compatibility Directive (2014/30/EU)
- Radio Equipment Directive (2014/53/EU)
- CE conformity date of issue: September 16, 2020

OBDLink CX Bluetooth radio equipment characteristics:


- Frequency range: 2400 MHz to 2483.5 MHz
- Radio Transmission Max Output Power: +2.2dBm



### **OBDLink CX Getting Started**



#### 1. Plug CX into the OBD port




OBD port is usually in driver's footwell

2. Get the OBDLink app




visit www.obdlink.com/apps or scan the QR code

**3.** Turn the ignition to the "Key On, Engine Off" position



**4.** Tap "Connect" in the OBDLink app



If prompted for a PIN, please enter

1 2 3 4 5 6