

Instrukcje+ — Uprozczone instrukcje obsługi.



Skullcandy Hesh 2 Instrukcja obsługi bezprzewodowej

[Strona główna](#) » [Skullcandy](#) » Skullcandy Hesh 2 Wireless Instrukcja obsługi 

Skullcandy
HESH 2
WIRELESS



zawartość

1 SZYBKI PRZEWODNIK

2 HESH WIRELESS INSTRUKCJA OBSŁUGI

2.1 Odniesienia

3 Powiązane posty

QUICK GUIDE



Uwaga: To urządzenie zostało przetestowane i uznane za zgodne z ograniczeniami dla urządzeń cyfrowych klasy B, zgodnie z częścią 15 przepisów FCC. Ograniczenia te mają na celu zapewnienie rozsądnej ochrony przed szkodliwymi zakłóceniami w instalacji mieszkalnej. To urządzenie generuje, wykorzystuje i może emitować energię o częstotliwości radiowej i jeśli nie jest zainstalowane i używane zgodnie z instrukcją, może powodować szkodliwe zakłócenia w komunikacji radiowej. Nie ma jednak gwarancji, że zakłócenia nie wystąpią w konkretnej instalacji. Jeśli to urządzenie powoduje szkodliwe zakłócenia w odbiorze radia lub telewizji, co można ustalić, wyłączając i włączając urządzenie, zachęca się użytkownika do podjęcia próby skorygowania zakłóceń za pomocą jednego lub kilku z następujących środków:

- ⚙ • Zmiana orientacji lub położenia anteny odbiorczej.
- Zwiększ odległość między urządzeniem i odbiornikiem.
- Podłącz urządzenie do gniazdka w innym obwodzie niż ten, do którego podłączony jest odbiornik.
- Aby uzyskać pomoc, należy zwrócić się do sprzedawcy lub doświadczonego technika radiowo-telewizyjnego.

To urządzenie jest zgodne z częścią 15 przepisów FCC. Eksploatacja podlega następującym dwóm warunkom: (1) To urządzenie NIE MOŻE powodować szkodliwych zakłóceń. i (2) To urządzenie musi akceptować wszelkie otrzymane zakłócenia, w tym zakłócenia, które mogą powodować niepożądane działanie. Producent nie ponosi odpowiedzialności za żadne zakłócenia radiowe lub telewizyjne spowodowane nieautoryzowanymi modyfikacjami tego urządzenia. Takie modyfikacje mogą unieważnić uprawnienia użytkownika do obsługi urządzenia.

To urządzenie jest zgodne z normą RSS-210 przemysłu Kanady. Działanie podlega następującym dwóm warunkom) to urządzenie nie może powodować szkodliwych zakłóceń. i (2) to urządzenie musi akceptować wszelkie otrzymane zakłócenia. W tym zakłócenia, które mogą powodować niepożądane działanie. Producent nie ponosi odpowiedzialności za żadne zakłócenia radiowe lub telewizyjne spowodowane nieautoryzowanymi modyfikacjami tego urządzenia. Takie modyfikacje mogą unieważnić uprawnienia użytkownika do obsługi urządzenia.

FCC ID: Y22-SK20130007

IC: 10486A-5K20130007

MODEL: Flesh 2

Sprzęt bezprzewodowy: V3

Oprogramowanie: V3

Funkcja Bluetooth: 2402MHz-2480MHz 0 0,34 dBm

HESH WIRELESS USER GUIDE

Główne elementy sterujące słuchawkami

Power On

- ⚙️ Press and hold the Main Function Button (MFB) (for up to 3 seconds) for the LED light ring to flash magenta and the ascending power on tone to be played. There will then be a blue LED double flash while the HESH Er looks to connect to up to 2 devices in the paired device list. If you have not yet paired to the device, and no paired devices are available for connection, the headphone will enter directly into pairing mode to be located by your device (see enter pairing mode instructions). If you have been paired to the Hesh BT previously, and your Bluetooth is enabled on your device, you will automatically connect and the voice notification "connected" will play.

Power Off

While in any mode (standby, pairing, streaming) press and hold down the MFB (for up to 5 seconds) and the Hesh ST will power off. As the headphone powers off, it will play the decending power down tone and the LED will flash magenta.

Enter Pairing Mode

When the headphone is OFF and you have not yet paired to your Hesh BT, press and hold the MFB (for up to 5 seconds) to reach the pairing mode. The LED will first flash magenta as the device powers on and you will then hear the voice notification "Pairing" as the LED begins to alternate red and blue. You are now in pairing mode. Scan for available devices and once HESH BT is selected, you will hear the voice notification "connected". Once paired, the LED will flash blue every 5 seconds.

Quick Connect to Device

If you have previously paired your device to your Hesh BT, simply press and hold the Main Function Button (MFB) (for up to 3 seconds) for the LED light ring to flash magenta and the ascending power on tone to be played. There will then be a blue LED double flash every 2 seconds while the HESH BT is in "device search mode" and looks to correct to a device in the paired device list. Ensure the device Bluetooth is ON; you will pair automatically and the voice notification "connected" will play.

Clearing the Device Paired List (*important with pairing issues')

If you have already paired to multiple devices and have any issues pairing, you will need to complete this action. Power ON the Hesh BT and while in "device search mode" hold the volume + and volume – buttons simultaneously for up to 5 seconds or until you hear a long double tone. This action will clear all devices that had previously paired to the Hesh BT, and you will then enter directly into pairing mode. Ensure the device Bluetooth is ON, and again scan for available BT headset devices for pairing.



Charging and Battery Status Check

When the micro USB charging cable is plugged in, there will be a red LED indicator next to the port that will turn on as long as the battery is charging. Once the battery is completely charged, the LED indicator will turn off. When the battery has dropped between 5%-10% of its total charge, LED light ring will begin to blink red and the voice notification "please charge device" will play approximately every 15 minutes. This is an indication that the Hesh BT should be charged via the provided micro USB to USB cable, or if you cannot

immediately re-charge, you have the option to continue listening via your 3.5mm AUX cable.

Expected Charging Time

When using the provided micro USB charging cable, a fully drained Flesh BT battery will take approximately 1.5 hours to fully re-charge to 60% battery life. At full volume, the BT steaming play time is about 15 hours.

Midi Cable Audio Playback

At any time, you may plug in the provided AUX Midi cable into the 3.5mm port located at the bottom of the left ear cup to activate the wired playback (it is recommended to power down the device before plugging in the aux cable). All track and volume controls on the physical headphone will be disabled however, you will still have full track control, play/pause, and call functionality, which can be utilized through the Midi cable and device.

Music Controls

Start Music Playback

When the Flesh BT is connected to the device but not streaming music, short press the round MFB to start streaming.

Pause Music Playback

When the Flesh BT is streaming music, short press the round MFB to pause the playback.

Volume Up

When the Flesh BT has been paired, you may rapidly press the + button to increase the volume level. You will hear a tone when the volume has reached its maximum.



Volume Down

When the Flesh BT has been paired, you may rapidly press the – button to decrease the volume level. You will hear a tone when the volume has reached its minimum.

Track Forward

When the Flesh BT is paired, press and hold the volume + button for up to 3 seconds to track forward.

Track back

When the Hesh BT is paired, press and hold the volume – button for up to 3 seconds to track back.

Phone Call/Receive Controls

On-Board Mic / Midi Cable and Volume function

When the Bluetooth is enabled, the on-board Mic and the volume + – Hesh BT buttons will be activated. If the 3.5mm aux cable is plugged in, the on-board Mic and volume + – buttons on the headset will be deactivated. When the Hesh BT is wired all controls will be enabled through the in-line Mid cable or device.

Voice/Mic Command Activation

When paired to the Hesh BT and not streaming music (standby), you may activate your voice command on your device through your on-board microphone with a double short press of the MFB.

Answer and Hang Up Call

When streaming BT, an incoming call can be answered with a single button press of the MS. Once connected, the call can be hung up with another single button press of the round MFB.

Reject incoming call

Long press (for up to 2 seconds) the MFB and the call will be rejected.

While call is active

Put on hold

When the call is active, long press (for up to 2 seconds) the round MFB. Once on hold, a short press of the round MFB will release the call on hold.



Mute Mic function

When the call is active, double short press the volume – button to mute the microphone, and double short press the volume + button to unmute.

Volume function

Short press the volume + to increase call volume, and short press the volume – to decrease the call volume.

NOTE:

To prevent possible hearing damage, do not listen at high volume levels for long periods. Excessive sound pressure from earphones and headphones can cause hearing loss.

Skullcandy Hesh 2 Wireless User Manual – [Optimized PDF](#)

Skullcandy Hesh 2 Wireless User Manual – [Original PDF](#)

References

- [User Manual](#)

Manuals+, Privacy Policy

Ta strona internetowa jest niezależną publikacją i nie jest ani powiązana, ani popierana przez żadnego z właścicieli znaków towarowych. Znak słowny „Bluetooth®” i logo są zarejestrowanymi znakami towarowymi należącymi do Bluetooth SIG, Inc. Znak słowny „Wi-Fi®” i logo są zarejestrowanymi znakami towarowymi należącymi do Wi-Fi Alliance. Jakiegokolwiek użycie tych znaków na tej stronie internetowej nie oznacza żadnego powiązania ani poparcia.

