


TWS Bluetooth Headphones

T1



User Manual

Please read the user manual thoroughly before use and keep it for future reference.

⚡ Packing list

⚡ **Headphones**

⚡ **Headphone case**

⚡ **User manual**

⚡ **Charging cable**

⚡ How to operate

Take the headphones out from the charging case. The headphones will turn on automatically.

⚡ **Pairing:** Turn on the Bluetooth of the mobile phone and find the name **"MIRO T1"**. Click connect to pair the headphones. The headphones will be automatically connected when you are using it next time.

⚡ **Play/pause:** Tap left or right headphone.

⚡ **Previous:** Double tap left headphone.

⚡ **Next:** Double tap right headphone.


⚡ **Answer:** When a call comes, double tap left or right headphone to answer the call.

⚡ **Reject:** When a call comes, long press 2s left or right headphone to reject the call.

⚡ **ANC:** While in standby mode, long press 2s left or right headphone will turn on/off ANC mode.

⚡ **Siri:** Three tap right headphone to enter Siri; and three tap left headphone to quit it.

⚡ **Low battery mode:** When the battery is less than 20%, you'll hear alerts every 5 minutes.



⚡ Specifications

Model name	T1
Bluetooth version	5.3+EDR
Operating frequency	2402MHz-2480MHz
Working distance	≤10M
Charging voltage	5V/400mA
ANC mode	6 Mics for ANC
Standby time	260 Hours
Speaker impedance	32Ω±15%

⚡ FAQ

⚡ What should i do if the bluetooth pairing is unsuccessful?

Occasionally there will be unsuccessful pairings. When it occurs, please ignore the connected Bluetooth device name in Bluetooth settings and turn off the device Bluetooth. Put the earphones in the headphone case for more than 10 seconds, then turn on the device Bluetooth, take the earphones out of the headphone case and wait for 5-10 seconds for the successful pairing.

⚡ What should i do if there is no sound from the earphones?

First: Please check if the headphones are paired to the correct device.

Second: Check the volume of the phone after connecting the headset to the phone. The maximum volume of the android phones is subject to the default volume of the phone.

Third: Make sure the headphones are properly charged. Make sure the sound is playing on the device (and not paused).

⚡ What should i do if there is occasional freeze/delay?

Since the headset is connected via bluetooth, occasionally, there will be a freeze or disconnection, please reconnect it when it occurs. When running large software, browsing some websites, or running software that occupies a large amount of memory, the Bluetooth loading time will be increased. This is not a quality problem of the headphones.

⚡ Precautions

⚡ Do not treat this product violently or squeeze it with heavy objects. Stay away from high temperature and high humidity environments.

⚡ Keep away from Wi-Fi, routers, and other high-frequency transmitting equipment. Those devices will generate radio interferences and cause the sound to be stuck or disconnected.

⚡ Please use this product in an effective distance (≤10m) and there should be no physical obstruction (such as walls, etc.) between the bluetooth device and the headphones.

⚡ If the LED on the headphone case does not turn on when opening or closing the headphone case, it is showing the power out status of the headphone case. In this situation, the automatic power on doesn't work. You need to touch the headphones manually to turn on the power.

⚡ FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Manufacturer
Foxx Development Inc.


Brand
MIRO

Phone
(+1) 855-585-3699

Address
3480 Preston Ridge Rd Suite 500, Alpharetta, GA 30005

Auriculares Bluetooth TWS

T1



Manual de usuario

Lea detenidamente el manual del usuario antes de usarlo y guárdelo para futuras referencias.

⚡ Lista de empaque

⚡ Auriculares

⚡ Funda para auriculares

⚡ Manual de usuario

⚡ Cable de carga

⚡ Cómo operar

Saca los auriculares del estuche de carga. Los auriculares se encenderán automáticamente.

⚡ **Emparejamiento:** Encienda el Bluetooth del teléfono móvil y busque el nombre **“MIRO T1”**. Haga clic en conectar para emparejar los auriculares. Los auriculares se conectarán automáticamente la próxima vez que los uses.

⚡ **Reproducir/pausar:** Toca los auriculares izquierdo o derecho.

⚡ **Anterior:** Toque dos veces el auricular izquierdo.

⚡ **Siguiente:** Toque dos veces el auricular derecho.

⚡ **Responder:** Cuando llegue una llamada, toque dos veces los auriculares izquierdo o derecho para responder la llamada.

⚡ **Rechazar:** Cuando llegue una llamada, mantenga presionados los auriculares izquierdo o derecho de 2 segundos para rechazar la llamada.

⚡ **ANC:** Mientras está en modo de espera, mantenga presionados 2 segundos los auriculares izquierdo o derecho para encender / apagar el modo ANC.

⚡ **Siri:** Tres toques con el auricular derecho para ingresar a Siri; y tres toques en el auricular izquierdo para salir.

⚡ **Modo de batería baja:** Cuando la batería está por debajo del 20%, escuchará alertas cada 5 minutos.



⚡ Características técnicas

Nombre del modelo	T1
Versión Bluetooth	5.3+EDR
Frecuencia de funcionamiento	2402MHz-2480MHz
Distancia de trabajo	≤10M
Voltaje de carga	5V/400mA
Modo ANC	6 micrófonos para ANC
Tiempo de espera	260 Horas
Impedancia del altavoz	32Ω±15%

⚡ Preguntas más frecuentes

⚡ ¿Qué debo hacer si el emparejamiento bluetooth no se realiza correctamente?

Ocasionalmente habrá emparejamientos fallidos. Cuando ocurra, ignore el nombre del dispositivo Bluetooth conectado en la configuración de Bluetooth y apague el Bluetooth del dispositivo. Coloque los auriculares en el estuche de los auriculares durante más de 10 segundos, luego encienda el Bluetooth del dispositivo, saque los auriculares de la carcasa de los auriculares y espere de 5 a 10 segundos para que el emparejamiento se realice correctamente.

⚡ ¿Qué debo hacer si no hay sonido de los auriculares?

Primero: Compruebe si los auriculares están emparejados con el dispositivo correcto.
Segundo: Verifique el volumen del teléfono después de conectar el auricular al teléfono. El volumen máximo de los teléfonos Android está sujeto al volumen predeterminado del teléfono.
Tercero: Asegúrese de que los auriculares estén cargados correctamente. Asegúrese de que el sonido se esté reproduciendo en el dispositivo (y no en pausa).

⚡ Precauciones

- ⚡ No trate este producto de forma violenta ni lo exprima con objetos pesados. Aléjate de ambientes de alta temperatura y alta humedad.
- ⚡ Manténgase alejado de Wi-Fi, enrutadores y otros equipos de transmisión de alta frecuencia. Esos dispositivos generarán interferencias de radio y harán que el sonido se atasque o se desconecte.
- ⚡ Utilice este producto a una distancia efectiva (≤10 m) y no debe haber obstrucciones físicas (como paredes, etcetera.) entre el dispositivo bluetooth y los auriculares.

⚡ **¿Qué debo hacer si hay una congelación/retraso ocasional?**
Dado que el auricular está conectado a través de bluetooth, ocasionalmente habrá un bloqueo o desconexión, vuelva a conectarlo cuando ocurra. Al ejecutar software de gran tamaño, navegar por algunos sitios web o ejecutar software que ocupa una gran cantidad de memoria, el tiempo de carga de Bluetooth aumentará. Este no es un problema de calidad de los auriculares.

⚡ Declaración de la FCC

Los cambios o modificaciones no aprobados expresamente por la parte responsable del cumplimiento podrían anular la autoridad del usuario para operar el equipo.

Este equipo ha sido probado y cumple con los límites para un dispositivo digital de Clase B, de conformidad con la Parte 15 de las Reglas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra interferencias dañinas en una instalación residencial. Este equipo genera usos y puede irradiar energía de radiofrecuencia y, si no se instala y utiliza de acuerdo con las instrucciones, puede causar interferencias dañinas en las comunicaciones por radio. Sin embargo, no hay garantía de que no se produzcan interferencias en una instalación en particular. Si este equipo causa interferencias dañinas en la recepción de radio o televisión, lo cual se puede determinar apagando y encendiendo el equipo, se recomienda al usuario que intente corregir la interferencia mediante una o más de las siguientes medidas:

- Reoriente o reubique la antena receptora.
- Aumentar la separación entre el equipo y el receptor.
- Conecte el equipo a una toma de corriente en un circuito diferente al que

está conectado el receptor.
• Consulte al distribuidor o a un técnico experimentado en radio/TV para obtener ayuda.

Este dispositivo cumple con la parte 15 de las normas de la FCC. El funcionamiento está sujeto a las dos condiciones siguientes: (1) este dispositivo no puede causar interferencias dañinas y (2) este dispositivo debe aceptar cualquier interferencia recibida, incluidas las interferencias que puedan causar un funcionamiento no deseado.

Fabricante
Foxx Desarrollo Inc.

Marca
MIRO

Teléfono
(+1) 855-585-3699

Dirección
3480 Preston Ridge Rd Suite 500, Alpharetta, GA 30005