





A	B	C	D
DISPLAY Watch hands 	SETTINGS Crown 3 positions  Push-button C Quick correction of day Day correction is not possible between 9.30 p.m. and 12 o'clock midnight Date correction is not recommended between 10 p.m. and 2 p.m. The moon phase cannot be corrected between 3 a.m. and 4 a.m.  Normal running of watch and hand-winding Rapid correction of moon phase, date and month Position for setting the time with stop second and correction of the date at every passing of midnight Self-winding of the watch by the movements of the wrist.	TIMING MODE Simple timing function  START 1 STOP 2 Read time - 4 hours - 10 minutes - 18 seconds Reset to zero 3 Setting crown in position I 1 to 3 order of functions	TIMING MODE ADD function  1 to 5 order of functions