

GP-LS 18/28 Li T BL
Cordless Pruning Shears




USAGE „HAND-MODE“

1) Off → Standby




2) Standby → On



WIDTH ADJUSTMENT

3) Cutting Width



4) Off

automatic



On → **Auto Standby**: 30 sec
Standby → **Auto shutoff**: 10 Min

manual



On → Off:
press 3 sec



On → Auto Standby:
Start-up lock + 5 sec

GP-LS 18/28 Li T BL
Cordless Pruning Shears



USAGE „TELESCOPIC-MODE“

1) Off → Standby



2) Standby → On



3) Off
automatic



30 sec standby + 10 min auto shutoff

manual



Press for **3 sec**
to switch off.