



Installation/Usage Instructions


How Can I Continue Using Zello App Without Upgrading?



STEP:1
Enter Menu




STEP:2
Click Options




STEP:3
Click Support



STEP:7
Restart



STEP:6
Cancel "Enable TLS"





STEP:5
Click and cancel



STEP:4
Advanced settings

How can I continue using Zello App without upgrading?

正面 单面126.3X168.3cm,总长756.3X168.3cm



FEATURES

- Nationwide Coverage
- Location Tracking and Monitoring
- Voice Recording and Playback

RT980

4G LTE NETWORK MOBILE RADIO

2G/3G/4G Switch Automatically • All Call, Group Call, Private Call

• GPS Function • Clear And Loud Voice

THANK YOUR FOR USERS

Thank you for purchasing RADIOTRAC POC mobile radio. RADIOTRAC products will always provides you with reliable, clear and high-efficiency communication services. Please read this Manual carefully and completely before using the transceiver, so that you can fully understand the performance, operating method and maintenance. Thank you.

Notices to the Users

- Do not attempt to operate your transceiver while driving, it is simply too dangerous.
- Do not operate the transceiver when you are nearby the blast area or blasting cap.
- Please switch off the transceiver when you are refueling or parking at the gas station.
- Please switch off the transceiver to avoid the problems caused by EMI and EMC, when you are in a place with a sign "Please switch off your transceiver".
- Do not modify the transceiver for any reason.
- Do not expose the transceiver to long periods of direct sunlight nor place it close to heating appliances.
- Do not place the transceiver in excessively dusty, humid or wet areas, or on unstable surfaces.
- Do not attempt to dismantle the transceiver unless professional technical personnel.
- Please use the designated antenna and power cable.

Ready to use the Mobile Perform the following steps to assemble your Mobile.

Install the SIM card

1. Open the SIM card slot.
2. Place the SIM card into the slot with right direction.
3. Lock the SIM card slot.

Note:

- Turn off the mobile before you inserting or removing the SIM card.
- Avoid touching the metallic area of the SIM card to prevent loss or damage to the information in the card and place it away from electromagnetic fields.

Install the main Antenna and GPS antenna

Power of the mobile, insert the antenna into the specified mounting hole and turn it clockwise, until tighten.

Install the Power supply cable

Insert the DC port of the power cable into the Power interface of the mobile; Insert the cigarette lighter port to your car's cigarette lighter.

Install the Suction cup holder

Pull up the handle on the back of the holder, put the holder on the place which you want to install, press down the holder to push out the air, then Pull down the handle of the holder.

You can adjust the angle of the mobile by clockwise rotate the two screws of the holder, then fix the mobile angle by anticlockwise rotate the screws.






Install the Microphone

Insert the Microphone crystal port into the Expansion interface. Please mind the direction of the Microphone crystal port.



Main Features

- ▶ Main Features
- ▶ Unlimited Talking Distance
- ▶ SIM card support GSM/WCDMA/LTE
- ▶ 1.77 Inch Colorful Display
- ▶ LCD Backlight & Brightness Selective
- ▶ Alphanumeric LCD Display Mode
- ▶ GPS Functional Optional
- ▶ Functional Dispatching System
- ▶ Compact & Heavy-duty Design
- ▶ All Call, Group Call & Individual Call
- ▶ Super Clear and Powerful Audio Output
- ▶ Content playback
- ▶ Dispatch Control


Standard Accessories




Hanger Microphone Cigarette lighter 4G Antenna Main Antenna Microphone Hanger



背面



Radio Overview



1. Knob: turn the volume counterclockwise +, rotate the volume clockwise -;
2. Power Button: Press and hold the button 3 seconds to power on/off;
3. Expansion interface: external extension interface such as link hand microphone accessory;
4. LCD Display;
5. UP Button: Short press to choose the functions upward;
6. Status Indicator;
7. DW Button: Short press to choose the functions downward;
8. Speaker;
9. OK button: confirm/selected button;
10. Lock screen button: Short press on/off screen, press and hold for more than 3 seconds to lock/unlock the keyboard;
11. Single call button: Short press to enter the member list and broadcast current user name, long press 3 seconds to send SOS;
12. Group call button: Short press to enter the group list and broadcast current group name, long press to play back all the audio records;
13. HOME button: Quickly return to the home page;
14. MENU button: Enter system settings;
15. Return button: return to the previous menu, no effect under the main menu; short press to exit the temporary intercom group during the temporary intercom mode;
16. SIM card slot;
17. Antenna interface: connect the main antenna;
18. GPS antenna interface: connect GPS antenna;
19. Power interface: connect the 13.8V car charging source;
20. Mounting bracket

LED Indication

	Power on status	Power on: press the power button, the green light is always on for 5 seconds and then off. Enter the boot screen, then start the animation, then the red light is always on for 15-20 seconds, enter the standby interface.
Led light Three states: 1. Flashing once (1 second), 2. Slow flash (once every 3 seconds), 3. Long bright	Network status indication	The red light flashes quickly: 1. SIM card is not activated or arranged, the terminal cannot register to the wireless network; 2. The quality of the wireless network is very poor, and the terminal cannot register; The red light is always on: 1. The SIM card is not installed or the SIM card is installed incorrectly, and the voice prompt "Mobile phone card reading failed"; 2. The device is not configured to be added on the service server. 3. Device has been added, group selector knob group mapping was not successful; 4. SIM card PIN code failed to be unlocked, voice prompt "PIN code error"; Flashing green light: Registering network status; The green light flashes slowly: the network has been successfully registered and entered the standby state; The green light is bright: Call status (single call/group call/temporary group)

Specifications

Items	Details
Modem	Qualcomm MSM8909
Technology	A7
Basic Frequency	1GHz
Operation system	Android based OS(5.1.1)
Network Frequency	■ GSM:Band2/3/5/8 ■ WCDMA:Band1/2/5/8 ■ TDD-LTE:Band38/40 ■ FDD-LTE:Band1/2/3/5/7/8/20/28
LTE CAT 4	TDD CAT4,FDD CAT4
Screen Size(inch)	1.77 Inch
Screen Resolution	128X160
Dimensions (without antenna)	170mmX54mmX39
Weight (including batter and antenna)	About 200g
Memory	ROM 4G RAM 4GB LPDDR3
Voice	MIC External Speaker Support MIC Support
Antenna	Main Antenna - External. Auxiliary antenna-FPC GPS/BO antenna - External
Mounting bracket	YES