
尺寸: 105x148.5mm 材质: 100g书纸 工艺: 单黑双面印刷 折页方式: 骑马钉



Wired Connection Usage

Connect one end of the USB A or USB C data cable to the computer, and plug the other end of the USB C connector into the keyboard. The keyboard backlight will light up and you can use the keyboard.



Keyboard Backlight Settings

& Keyboard backlight color setting

The backlight color will cycle in the following order: white \rightarrow red \rightarrow yellow \rightarrow green \rightarrow cyan \rightarrow blue \rightarrow purple \rightarrow white.

When the computer is turned on, the keyboard defaults to the second level of backlight brightness. After pressing the $\frac{2^{1}}{3}$ key, the backlight brightness will be adjusted in the following order: Level 2 \rightarrow Level 3 \rightarrow Level 1 \rightarrow Off.

.

Multimedia Function Keys

Key	Mac OS	Windows
Esc @	FN lock	FN lock
* F1	Brightness -	Brightness -
# F2	Brightness +	Brightness +
BD F3	Task Center	Switch Task Windows
988 _{F4}	Switch Task Windows	Task View
□ _{FS}	Return to Desktop	Return to Desktop
Q F6	Search	Search
⊟ _{F7}	Select All	Select All
Q F8	Сору	Сору
λ _{F9}	Cut	Cut
图 F10	Paste	Paste
↓ FTI	Mute	Mute
△ F12	Task Center	Web Page
@	Screenshot	Screenshot
٥	No Function	Settings
	No Function	Calculator
9	Lock Screen	Lock Screen
≡	No Function	Menu

Note: By using the FN lock key, you can switch between the standard functions and multimedia functions of the F1 to F12 keys.

Product Parameters

≤5mA
≤170mA
20uA
Press any key
480x244x26mm
Windows XP, Windows 7~11 systems; Mac Book system

s

- When you restart the computer, the backlight setting will not be remembered, but when you wake up from sleep mode, the backlight setting will be retained.
- In order to save power and protect the environment, if there is no key operation within 10 minutes, the keyboard will automatically enter sleep mode and turn off the backlight. To turn the backlight back on, just press any key.

Sleep Mode

- The keyboard will automatically enter the sleep mode after 10 minutes of inactivity and the indicator light will be off.
- Please press any key to wake up the keyboard. The indicator will light up again and starts to work within 1 second.

Packaging Content

- Keyboard *1
- ▶ USB & USB-C Combo to Type-C Data Cable *1
- User Manual *1

Safety Warning

IMPORTANT: To reduce risk of fire, electric shock, or injury, follow these safety instructions.

- Heat Exposure: Avoid leaving the item in high-temperature environments or in direct sunlight, which could result in a fire hazard.
- Liquid Exposure: Keep the item away from water and liquids. Do not use if wet until thoroughly dried,
- Damage and Leakage: Cease usage and consult customer service if the item is damaged or the battery leaks.
- ▲ Correct Disposal: Follow local regulations for disposing of electronic devices and batteries. Do not dispose of with household waste.
- Radio Frequency Interference: This device may cause interference with other electronics, Keep a safe distance from sensitive devices,
- Child Safety: Keep the item and its components out of reach of children to avoid choking or battery ingestion hazards, Never allow children to handle the item unsupervised.

CAUTION: Non-compliance with the above warnings can lead to serious injury or property damage.

For further assistance or information, please contact our customer service.

Email: support@seenda.com

-5-

-6-