



# ARTEMIS

**MECHANICAL GAMING KEYBOARD  
OUTEMU SWAPPABLE SWITCH**



**USER MANUAL**

Wired USB Connection  
for Laptops and PCs

68 keys Keyboard

Spectra RGB lighting effects,  
more than 10 LED lighting mode



Software support to control  
Macros and customize RGB lights

Injection Molded  
Double-shot Color Keycaps

- Win-Key Lock Windows Buttons can be disabled.
- Simultaneous Operation for All Keys Without Any Key Ghosting Effects.
- 50 million + Operations for Each Key.



Visit [www.thecosmicbyte.com](http://www.thecosmicbyte.com) to download  
software for the keyboard

## SPECIFICATIONS

• System	Windows, Mac
• Switch Working Life	OUTEMU 50 million times
• Key Number	68keys US layout
• Product Interface	USB C to USB A
• Cable	PVC Cable 1.7m
• Current Consumption	max.200mA
• Size	292*102*40mm
• Weight	560g

## MULTIMEDIA FUNCTIONS

### Multimedia Key Combination

FN + 1	F1
FN + 2	F2
FN + 3	F3
FN + 4	F4
FN + 5	F5
FN + 6	F6
FN + 7	F7
FN + 8	F8
FN + 9	F9
FN + 0	F10
FN + -	F11
FN + =	F12
FN + [	PrtSc
FN + ]	ScrLk
FN + ;	PauBr
FN + ' /	INS

### FN Combination Keys

FN + . ,	HOME
FN + / \	END
FN + Win	Win lock
FN + Ctrl(R)	Search
FN + PgDn	Volume -
FN + PguP	Volume +
FN + Rt ALT	Mute
FN + DEL	Switching Lighting Effect
FN + ~	Change Single Color
Lighting	
FN + \	User-Defined Lighting
FN + ↑	Increase LED Brightness
FN + ↓	Decrease LED Brightness
FN + →	Increase Speed of Dyna-
mic Lighting	
FN + ←	Decrease Speed of Dyna-
mic Lighting	
FN + Space	Lighting On/Of

## REPLACING THE SWITCHES



The Artemis keyboard is upgraded to support Swappable Outemu switches. This means that switches are not soldered onto the PCB, and you can easily remove and replace switches.

This helps to increase the life span of the keyboard. If any of the switch stops working just use the included Keycap and Switch puller to remove the keycap and switch and replace the switch with a new one.

You can also change the switch colour to any Blue, Red, Brown or other Outemu Swappable Switches to customize the keyboard as you require without any hassle.



SCAN QR CODE FOR  
VIDEO GUIDE

# TROUBLESHOOTING

## 1. Resetting the Keyboard

**Ans:** If you face any issue with the keyboard, we will first recommend you reset the keyboard by pressing FN+ESC key for 3 seconds. This will reset the keyboard to its factory default settings.

## 2. PC not detecting keyboard

**Ans:** Kindly try and change the USB port used to connect the keyboard. We recommend you connect the keyboard directly to the back of the PC to avoid any issue with detection. Use of USB extensions can cause the PC failure in detecting the Keyboard.

## 3. Additional Support:

**Ans:** Contact our customer care team on [cc@thecosmicbyte.com](mailto:cc@thecosmicbyte.com) to troubleshoot or claim warranty. Please note warranty will not be valid if purchased from Unauthorized Sellers or for products tampered by third party technicians.

## SUPPORT DETAILS

Contact no: 07969273222 (Mon-Sat 10am to 6pm)

Email: [cc@thecosmicbyte.com](mailto:cc@thecosmicbyte.com)

## WARRANTY

The Keyboard carries 1 Year warranty against manufacturing defects only.  
Physical, Water damage and Tampered products are not covered under warranty.  
Regular wear and tear from battery usage is not covered under warranty.



[Scan the QR code to know the Warranty Claim Procedure.](#)

## FAQ'S

[support.thecosmicbyte.com](https://support.thecosmicbyte.com)