



# Stellar


## AIR



.....

TURNING VENT COVERS INTO ART


## How To Install Your Stellar Air Metal Screw-In Register



Remove standard register from floor



Line up the Stellar Air register



Screw in the registers from the pre-drill holes. If your vent does not have pre-drill holes, make sure to add before installation



Note: If you would like your register to sit flush to your hardwood floors, you can router your floors 1/16" deep



Enjoy your Stellar Air return air register

## *Safety & Additional Instructions*

Registers are black painted, this finish gives a protective coating that will resist staining or corrosion.

- ✿ Ensure that the return air opening is sized properly before installing. For information about measuring, please visit: [stellarairdecorativevents.com](http://stellarairdecorativevents.com)
- ✿ Some Stellar Air products have designs with small openings. Keep small children away from covers.
- ✿ To clean your Stellar Air product, use a dry soft bristle brush or duster. You can use a blush vacuum to remove any dust with a wet cloth.

Thank you for Choosing us!!  
For instruction videos or more information about  
Stellar Air, please visit  
our website [www.stellarairvents.com](http://www.stellarairvents.com) or call us  
at 843-795-6680  
[www.stellarairdecorativeeventcovers.com](http://www.stellarairdecorativeeventcovers.com)  
[info@stellarairvents.com](mailto:info@stellarairvents.com)

