



Stellar


AIR



.....

TURNING VENT COVERS INTO ART

How To Install Your Stellar Air Metal Screw-In Register



Remove standard
register from floor



Line up the Stellar Air register



Screw in the registers from the
pre-drill holes. If your vent does not
have pre-drill holes, make sure to add
before installation



Note: If you would like your register to sit
flush to your hardwood floors, you can
router your floors 1/16" deep



Enjoy your Stellar Air
return air register

Safety & Additional Instructions

Registers are black painted, this finish gives a protective coating that will resist staining or corrosion.

- ✿ Ensure that the return air opening is sized properly before installing. For information about measuring, please visit: stellarairdecorativevents.com
- ✿ Some Stellar Air products have designs with small openings. Keep small children away from covers.
- ✿ To clean your Stellar Air product, use a dry soft bristle brush or duster. You can use a blush vacuum to remove any dust with a wet cloth.

Thank you for Choosing us!!
For instruction videos or more information about
Stellar Air, please visit
our website www.stellarairvents.com or call us
at 843-795-6680
www.stellarairdecorativeeventcovers.com
info@stellarairvents.com

