



Sony Clie PEG-SL10 Scroll Wheel Replacement

Written By: Emily



TOOLS:

Phillips #0 Screwdriver (1)

Step 1 — Scroll Wheel



- Remove the six screws holding the outer case of the Sony Clie.

Step 2



- Remove the two screws holding the scroll wheel.

Step 3



- Pull the two plastic tabs away from the motherboard.

Step 4



- Remove the scroll wheel from the device.

To reassemble your device, follow these instructions in reverse order.

