## Single Flush





## THANK YOU!

Dear Valued Customer,

Thank you for choosing our ceramic Two-Piece Toliet. We hope our products can improve the quality of your life.


As a valued customer, your comments and opinions are very important for us. If you have any concerns, questions, or comments, we hope that you could bring them to our attention.

Please keep the box and packaging materials until your product is completely installed.

If you have nay questions or concerns, please contact us:

607-645-4819 info@hopze.com

Sincerely





## Prior to Installation:


- Before installation, please make sure that the toilet without damaged during shipping.
- Observe all plumbing and building codes in accordance with your state and local requirements.
- Remove old toilet.
- Make sure mounting surface is CLEAN and LEVEL...

#### **General Recommendations:**

Please read installation and maintenance instructions thoroughly before installing the toilet.

Be sure to use proper tools and always wear proper personal safety accessories for your protection.

#### SUGGESTED TOOLS AND MATERIALS



Installation tools are not provided, please prepare by yourself.

#### PARK LIST

Push button, tank lid, water fitting, soft-close toilet seat, wax ring, bolts kit, bolt covers, installation instruction.

The step-by-step guidelines in the installation instructions are a general reference for installing a Two-Piece Toilet. Should there be any discrepancies, we cannot be held liable. It is recommended to install all Products by hiring a licensed professional.



- 1. Read the complete instruction manual before beginning installation.
- Confirm that your model will fit in intended location and plumbing fixtures are located where legally required before beginning installation.



Not all drawings on this manual are drawn to scale. Please refer to the model chart.



- Two people are recommended to install and move this product.
- 5. Product is FRAGILE! To avoid breakage and possible injury handle with care.

NOTE: Specialized tools may be necessary to install the Two-Piece Toilet, plumbing not included.

#### INSTALLATION STEPS


#### 1. Remove Old Toilet

- Turn off the water supply.
- Flush the toilet to empty the tank. Remove any water left in the tank or bowl.
- Disconnect the supply line from the tank.
- Remove decorative caps. Unscrew nuts that attach the toilet to the floor.
- Remove toilet.
- Make sure the water supply valve is shut off before installation.
- Remove old closet bolts from closet flange. Clean any old wax, putty, etc. from base area.

#### IMPORTANT NOTE REGARDING WATER SUPPLY:

Before installation ensure that the shut-off valve is greater than 7 1/2" from the center of the drain to the center of the shut-off valve on either side.

NOTE: This is a true 12" rough-in toilet from finished wall to center of the drain (no less than 12"). Baseboard thickness may reduce rough-in dimension.




NOTE: Drawings may not exactly define contour of the product.

#### 2. Install Toilet Floor Bolts

Install Floor bolts to flange channel, turn 90° and slide into place 6" (152mm) apart and parallel to wall.

Note: 1) Ensure top surface of the drain flange is flush to the finished floor, or does not exceed 1/2" (1.27 cm) above the finished floor. Otherwise, consult with a plumbing professional.

Toilet Flange is not included.




#### 3. Install Wax Ring



 Invert toilet on floor (use cushion to prevent damage), and install wax ring evenly around waste flange, with tapered end of ring facing toilet.


#### 4. Position Toilet on Flange



- Lower the toilet onto the closet bolts, so the bolts project through mounting holes in base of toilet.
- Rock to press the bowl completely downward on the wax ring and flange.




- Apply weight evenly until toilet is flush to the floor.
- Do not move after placement or watertight seal may be broken.



- Install the washer and nut in sequence, then alternately tighten the nut until the toilet is firmly sealed to the floor.
- Install the cap.

NOTE: Drawings may not exactly define contour of the product.


#### 5. Install Toilet



 Place the tank gasket over the tank nut ensuring there are not gaps between the gasket and the tank.





 Put the two tank bolts into the tank mounting holes, then pick up the tank and connect it after guiding the bolts to align the tank with the bowl.



 Tighten nuts alternately to make them stable on the toilet bowl.

#### 6. Install Toilet Seat






- Take out the seat cover and the hinge parts from the packing bag. Check out the contents to make sure all parts are
  included. Take out the plastic bolt and rubber washer and assemble them to the hinge. Then place the seat cover with
  the hinge onto the toilet seat. Insert the bolts into the toilet seat holes. Adjust the seat cover to make it match the
  toilet seat.
- Install the rubber stopper and plastic washer to the bolt and tighten the nut. Then put the hinge cover to complete the installation.

NOTE: Drawings may not exactly define contour of the product.


#### 7. Install Flush Button- Single Flush Button on Side Water Tank Style

#### I. Installation Profile




#### II. Steps


- Preparation
   Clean the tank and pipe.
- 2. Installation




Disassemble the adapter and inlet nut for fill valve installation Position valve inside tank. Push down on the valve shank (not the top) white tightening inlet nut. Screw the valve shank clockwise and pull the valve body to the correct height.




Adjusting the water level by removing the clip and turn outer float to the right position. Move the floats up or down along the valve body to the desired height. Click back into position and replace plastic clip.



Twist the valve body out of the base.




Disassemble outer nut, outlet washer for flush valve installation. Position the valve inside tank. Push down on the valve body while attaching outlet washer and lightening outlet nut. Make sure the seal washer touches surface of cistern firmly.



Side the re-fill tube over the re-fill tube port. Trim the re-fill tube to right size to prevent kinking, insent the other end of the re-fill tube onto the re-fill cap of overflow tube.



Twist the nut and washer out of the handle



Insert the level into the tank through the handle hole. Adjust the direction of handle according to above figure. Tighten the washer and nut.

Possible Reason

Blockage in water

supply;in-correct

position

Fault with in-let.


installation (loose);

Surface of cistem

in-correct float

float valve adjustment, correct position

supplier



Attach the hook to the hole of lever. Check whether the length of the chain is appropriate. The flush valve can not work normally if the chain is too long. Too short chain may lead to leakage.

Solution

Check both fill valve and water supply

line for blockage; Adjust float valve to

Adjust float valve to correct position

Check screw for fitment and relighten

if necessary; Contact your ceramic

#### III. Trauble Shooting Guide

#### 1. Flush Valve

No.	Issue	Possible Reason	Solution
1	Water leaking from outlet	Valve not installed correctly	Check installation and re-tighten
2	Water leaking from flapper seet	Broken washer, Debris on washer / fapper, Length of chain is too short	Change washer; Clean washer with warm water so surface is clear; Adjust length of chain
3	Flush valve not working	Length of chain is too short	Adjust length of chain

Please keep the instruction for future use.

Products may be amended in line with continuous improvement, please refer to actual product.

### NOTE: Drawings may not exactly define contour of the product.

2. Fill Valve

Issue

Erratic or

no water fill

Water level too

Water leaking

from base of fill

high / low

walve