


TESLONG

7-inch Inspection Camera User Manual



Model No.: NTS700

Overview


Features

- 7-inch HD IPS Screen
- 180°Image Rotation
- Split Screen View (Only for Dual/Triple Lens)
- Led Camera Lights & Led flashlight
- Detachable Probe Design
- Supports Wifi Connection
- PD Fast Charging

Applications

- Automotive or diesel repair and maintenance
- Inspection of hard-to-reach or hard-to-see areas or equipment, plumbing, construction & restoration applications
- Scientific education
- Outdoor exploration
- Rescue security

Safety

 **WARNING!** Please read all safety warnings and instructions before using this product. Failure to follow these warnings may result in electric shock, fire or serious injury.

- Keep the tool dry, clean, free from oil, water, gas or other materials that may cause corrosion.
- This appliance is not intended to use for people with limited physical, sensory or mental capabilities.
- This appliance is not intended for medical use. Keep bystanders or children away while operating the tool.

Maintenance

- Keep the camera lens clean.
- Keep the working area clean.
- Charge the device at least once every 3 months if it is left unused for a long time to prevent damage to the battery.

Specifications

Monitor	Screen Type	7-inch HD IPS Screen
	Image Rotation	180°
	Monitor Resolution	1280 x 720
	Port	Type-C USB, TF Card Slot, HDMI Port


Camera	Single Len/Dual Lens /Triple Lens
Cable Length	1M/3M/5M
View Angle	78°
Split Screen	Yes (Only for Dual/Triple Lens)
Video Resolution	Max to 1920x1080
Image Resolution	Max to 1920x1080
Waterproof	Camera & Cable IP67
Light Source	Adjustable LED camera lights LED flashlights on the back of device

Others	Operating Temperature	-4°F to 140°F (-20°C to 60°C)
	Power Source	6000mAh Lithium Polymer Battery
	Runtime	About 4h
	Charging Time	About 3.5h
	Input	5V = 1.5A /9V = 1.5A/12V = 1.2A Supports PD Fast Charging
	Work Voltage	3.7V


★ For more probe/cable options please visit the official Teslong website and store: Teslong.com.


 **NOTICE:** Should you need replacement(s) of any other components, please contact our customer service for help.

Functions




- ① Cable Port
- ② Camera light button: To adjust the camera LED's brightness
- ③ Snap Button: Press , Photo Taking/Video Recording Start/End
Hold, Switch the camera view
- ④ Mode button: Photo taking/video recording/view album
- ⑤ UP button
- ⑥ Setting Button: Press, Enter/Exit setting menu
Hold, Turn On/Off WiFi signal
- ⑦ OK button: Confirm selection/freeze screen
- ⑧ Down/Rotate button
- ⑨ Power button: long press to turn on/off
- ⑩ Type-C Charging Port
- ⑪ TF card slot (micro-SD)






- 12 Speaker 13 Led flashlight 14 1/4" Screw hole for metal stand
 15 Led flashlight button 16 HDMI Port 18 Microphone
 17 Reset button 19 Metal stand

Using your inspection camera




Remove the plastic screen cover before using this device.




Connect the cable to the monitor (make sure the camera is connected firmly to get the best image on the screen)

Using your inspection camera



Power ON/OFF
(Press and hold the Power Button to turn on the device.).



The device is equipped with a TF memory card(inserted). Please make sure it's installed before use.

How to insert a TF card:

- Power On the device first before inserting TF card.
- Make sure the orientation of the TF card is correct when inserting into the slot.
- Do not use excessive pressure when inserting or removing the TF card from the slot.
- Only take photos or record videos when a TF card is inserted.
- This device requires Class 10 high speed TF card – it will not work properly with Class 4 low speed card.

Power Button Lighting Details



Device Running: Blue LED stay on






Charging(Device on): Red/Blue LED flashes



Charging(Device off): Red LED stay on

Modes & Setting

Mode: Press **[M]** to switch between three modes:
 photo taking/  video recording/  Album

TF card status: TF card inserted/no card




Date and time: modify the date and time in Settings menu

Switch take photos and video recording


Take Photo



Press **[M]** to switch to “take photo” mode, and press  to take a photo.

Video Recording



Press **[M]** to switch to “video recording” mode, and press  to start recording.


In any modes, press the  button twice to enter the system settings menu.

Click   button to select and  button to save the changes.

The default language is English, and the system supports English, Chinese, German, French, Spanish, Italian, Russian and Japanese.

How to Switch the view of Camera (Only for Dual/Triple Lens)

Hold the photo button to switch the view of the Front Camera/Side Camera.




WiFi Connecting: how to display the image on your Phone/Pad/Tablet




Use your phone to scan the QR code and download "Smart Endoscope" app.




Enable the device WiFi in the settings menu.




Connect the WiFi (At this time, the host's WiFi indicator  blinks.)




Start displaying the image on your phone/pad/tablet



Click the  button in the app to set up the device and start using it with your smartphone.




Run the app.

 Please note Photo Taking/Video Recording ONLY supported by your Phone/PAD/Tablet (not available for the endoscope device) when in the WiFi mode.


Scan the QR code or enter the activation code printed on the card to remove the ads in the app.

Transfer photo/video files to your computer




1. Use a TF card reader to Transfer data directly.
2. Connect your computer with Type-C USB cable to transfer files.

⚠ Pull out probe camera first before using USB cable.



Please use a USB wall charger that supports PD fast charging and the appropriate cable to charge your device.



If the device crashes, please press the reset button to restore it.



EU Environmental Protection

Do not dispose of old electrical products with your household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.



Customer Service

Please contact us if you have any questions about our products, we would love to hear from you.



12-month Limited Warranty



Lifetime Technical Support



support@teslong.com | info@teslong.com



1-877-899-8809 (US)
(Mon-Fri 9:00 AM-5:00 PM PST)



© TESLONG NTS700 C0316V1.1
3.06.04.000901